

SpecoBlue VMS Enterprise

User Manual

SB01M



Notes

- Please read this user manual carefully to ensure that you can use the device correctly and safely.
- There may be several technically incorrect places or printing errors in this manual. The updates will be added into the new version of this manual. The contents of this manual are subject to change without notice.
- This device should be operated only from the type of power source indicated on the marking label. The voltage of the power must be verified before using the same. Kindly remove the cables from the power source if the device is not to be used for a long period of time.
- Do not install this device near any heat sources such as radiators, heat registers, stoves or other devices that produce heat.
- Do not install this device near water. Clean only with a dry cloth.
- Do not block any ventilation openings and ensure proper ventilation around the machine.
- This machine is for indoor use only. Do not expose the machine in rain or moist environment. In case any solid or liquid get inside the machine's case, please turn off the device immediately and get it checked by a qualified technician.
- Do not try to repair the device by yourself without technical aid or approval.

Contents

1	Introduction	1
1.1	Welcome	1
1.2	Front &Rear Panel Instructions	1
2	Login	2
2.1	Login	2
2.2	Quick Wizard Settings	3
2.3	Main Menu Interface Introduction	4
3	Device Management	8
3.1	Add Encoding Device	8
3.1.1	Quickly Add	8
3.1.2	Manually Add	8
3.1.3	Auto Report	10
3.1.4	Quickly Add Auto Report Device	10
3.2	Modify or Delete Device	11
3.3	Device Area Selection	11
3.4	Batch Import/Export	11
3.5	Device Upgrade	12
3.6	Device Setting	12
3.7	Area Setting	12
3.8	Server Settings	13
3.9	Channel Group Settings	14
3.10	Task Management	14
4	Group Management	16
4.1	People Management	16
4.1.1	Add Group	16
4.1.2	Add Target	17
4.1	Vehicle Management	19
4.1.1	Add Vehicles	19
4.1.2	View, Modify or Delete Vehicles	20
4.1.3	Import or Export Vehicles	20
4.2	Permission Management	21
5	Search	25
5.1	Image Search by Face	25

5.2	Face Comparison Search.....	26
5.3	License Plate Comparison Search	26
5.4	Smart Snapshot Search.....	27
6	Face Greeting	30
7	Face Attendance.....	33
7.1	Add Devices and Targets.....	33
7.2	Attendance Configuration.....	33
7.2.1	Attendance Check Point Settings.....	33
7.2.2	Attendance Period Settings.....	34
7.2.3	Attendance Shift Settings	36
7.2.4	Personnel Scheduling	36
7.2.5	Attendance Handling.....	37
7.2.6	Holiday Settings.....	40
7.2.7	Basic Configuration	40
7.3	Search Attendance Record.....	40
7.4	Statistics of Attendance Data	42
7.5	Real-time Monitoring	42
7.5.1	Real-time Monitoring	42
7.5.2	Data Synchronization	43
8	Face Access Control.....	44
8.1	Add Face Recognition & Access Control Device.....	44
8.2	Permission Settings.....	44
8.3	Event Linkage.....	45
8.4	Record Search.....	45
8.5	Two-Way Talk.....	46
8.6	Real-Time Monitoring.....	46
8.7	E-Map Access Control.....	46
9	Video Preview	47
9.1	Video Preview.....	47
9.1.1	Monitoring Point View	48
9.1.2	Channel Group View	49
9.2	Smart View	51
9.2.1	Face Comparison.....	52
9.2.2	License Plate Comparison	55
9.3	Plan View.....	58
9.4	PTZ Control.....	59
9.5	Instant Playback.....	60
10	Record & Playback	61
10.1	Record Configuration	61
10.1.1	Schedule Recording	61
10.1.2	Alarm Linkage Recording.....	62
10.2	Playback.....	63
10.2.1	Normal Playback	63
10.2.2	Smart Playback by Face	65
10.2.3	Smart Playback by License Plate	67
10.2.4	Playback by Time.....	67
10.2.5	Playback by Event.....	68
10.2.6	Playback by Tag	69
10.3	Record Backup	69
10.4	Search Picture.....	70
11	Alarm Management	71
11.1	Alarm Server Configuration	71
11.2	Alarm Configuration	71
11.3	SOP Settings.....	73
11.4	Alarm Task Settings.....	73

11.5	Email Setting	74
11.6	Alarm View	75
11.7	Alarm Log.....	76
11.8	Manual Alarm Out	77
12	E-Map	78
12.1	E-Map Settings.....	78
12.1.1	Create E-Map	78
12.1.2	Add Hotspot	78
12.2	E-Map Monitoring	79
13	TV Wall	80
13.1	Add Device.....	81
13.1.1	Add Decoder	81
13.1.2	Create and Connect Decoder	81
13.2	TV Wall Management	82
13.3	TV Wall System Settings.....	83
13.3.1	Channel Number Settings	83
13.3.2	Decoder Setting.....	83
13.3.3	TV Wall Alarm Linkage Settings.....	83
13.4	Video Preview.....	84
13.4.1	Decoder Input	89
13.4.2	Playback	89
13.5	TV Wall Task Setting.....	90
13.6	TV Wall Backup	92
14	Target Counting	93
14.1	Task Management	93
14.2	Real-time Statistics	93
14.3	Heat Map	94
14.4	Historical Statistics.....	95
14.5	Flow Control	95
15	Visitor Management	98
15.1	Add Access Control Devices.....	98
15.2	Apply for a Visit	98
15.3	Search and Export Visitor Record	101
15.4	Exception Handling	101
15.4.1	Extending Visit Time or Modify Access Point	101
15.4.2	Not Visiting/Leaving Beyond the Given Time	102
16	Parking Lot Management	104
16.1	Add Devices	104
16.2	System Settings.....	105
16.2.1	Parking Lot Settings	105
16.2.2	Vehicle Group Management	108
16.2.3	Block List Management	111
16.3	Vehicle Monitoring	111
16.3.1	Real-time Vehicle Preview	111
16.3.2	Pass Records.....	112
16.3.3	Pass Information	112
16.4	Integrated Search	112
16.4.1	Search Pass Information.....	112
16.4.2	Search Overdue Parking	113
16.4.3	Search Vehicles in the Parking Lot.....	113
16.5	Report Statistics.....	113
17	Body Temperature Measurement.....	115
17.1	Add Temperature Reading Devices	115
17.2	Temperature Screening.....	115
17.2.1	Configuration	115

17.2.2	Live Preview	116
17.2.3	Record Search	117
17.2.4	Statistics	117
18	Industrial Temperature Measurement	119
18.1	Thermal Network Camera Settings	119
18.1.1	Temperature Measurement Settings	119
18.1.2	Temperature Alarm Settings	119
18.1.3	Fire Detection Settings	120
18.1.4	Alarm Linkage Settings	121
18.2	Temperature Measurement	121
18.2.1	Video Preview	121
18.2.2	Data Analysis	122
18.2.3	Record Search	123
19	User Management	125
20	Operation and Maintenance Management	127
20.1	Check and Export Log	127
20.2	Backup and Restore Configuration	127
20.3	Viewing Online Status	127
20.4	Viewing Status Log	128
21	Configuration	129
21.1	Local Configuration	129
21.1.1	Basic Settings	129
21.1.2	Resource Tree Settings	129
21.1.3	Record and Snapshot Settings	130
21.1.4	Alarm View Settings	130
21.1.5	Overload Settings	130
21.1.6	Snapshot Attribute Display Settings	131
21.1.7	Network Configuration	131
21.1.8	Server Port Configuration	132
21.1.9	System Time Configuration	132
21.1.10	Upgrade System	133
21.1.11	Other Configuration	133
21.2	Server Configuration	133
21.2.1	System Settings	133
21.2.2	Alarm Settings	134
21.2.3	Parking Lot Settings	134
21.2.4	Audio Uploading Settings	134
22	Data Dashboard	135
22.1	Create Intelligent Dashboard	135
22.2	Basic Module	136
22.3	Face Comparison Display	137
22.4	Body Temperature Measurement Display	138
22.5	E-map Display	139
22.6	Smart Snapshot Display	141
22.7	Traffic Flow Statistics Display	141
22.8	Remaining Parking Space Display	142
23	Troubleshooting	143

1 Introduction

1.1 Welcome

Thank you for purchasing this product.


If technical assistance is needed, please contact Speco Technologies Technical Support.

Phone: 1-800-645-5516 option 3

Email: techsupport@specotech.com

1.2 Front &Rear Panel Instructions

The picture below is for reference only.



No.	Description	No.	Description
1	USB3.0 *2	7	Power button (LED)
2	Ethernet port (LAN)	8	USB3.0 *1
3	USB2.0 *2	9	USB3.0 *1
4	HDMI output	10	Audio Input
5	VGA output	11	Audio Output


2 Login

2.1 Login

Before starting, please make sure network cable, monitor and power are connected. After the server is started, the following window will appear as shown below.

Server mode or client mode can be selected when logging in. If “Client mode” is selected, you need to enter the address and port of the authentication/management server. Then this server will be used as a client. If “Server mode” is selected, this server can be used directly.

Taking server mode as an example:




① Enter username and password (the default username is admin; the default password is 1234).

Check “Remember Password” or “Auto Login” as needed. If it is the first time for you to log in, you must check “I have read and agree Application Privacy Statement”.

② Click [Login].


If you forget the password, please click “Forget password”. Then a small window will appear. You can reset the password by answering the pre-defined questions.



If you don't set or forget the security questions and answers, you can reset your password by dynamic password. Click “Forget password” and then click “Dynamic Password” to go to the dynamic password page. Search the CPU ID, MAC address and the current time and then send the information to the technical staff to get the dynamic password.

2.2 Quick Wizard Settings

After you log in, a wizard will display and the password modification is required.




The screenshot shows the 'Quick Configuration Wizard' interface at the 'Modify Password' step. The breadcrumb trail includes: Modify Password, Create Security Questions / Answers, Network Config, System time config, Device Time Correction, and Select a plan. The 'Modify Password' step is active. It contains two text input fields: 'New Password' (placeholder: 'Please enter password') and 'Confirm Password' (placeholder: 'Enter password again'). Below these is a 'Password strength' section with three radio buttons: 'Weak', 'Middle', and 'Strong'. The 'Strong' option is selected. A red text note below the radio buttons reads: '8-16 characters, numbers, special characters, upper case letters and lower case letters must be included'. A 'Next' button is located at the bottom right of the form.

If this is the first time for you to log in, it is recommended to create security questions and answers.


It is important that you remember the answers for these questions or you will not be to reset your password and be locked out.

Click "Skip" to skip the following wizard setup.




The screenshot shows the 'Quick Configuration Wizard' interface at the 'Create Security Questions / Answers' step. The breadcrumb trail includes: Create Security Questions / Answers, Network Config, System time config, Device Time Correction, and Select a plan. The 'Create Security Questions / Answers' step is active. It contains three sets of 'Question' (dropdown menu) and 'Answer' (text input field) pairs. At the bottom left, there is a checkbox labeled 'No more tips for security questions'. At the bottom right, there are 'Next' and 'Skip' buttons.

Click "Next" to enter the network configuration interface. Set the network parameter according to the actual condition.




The screenshot shows the 'Quick Configuration Wizard' interface at the 'Network Config' step. The breadcrumb trail includes: Create Security Questions / Answers, Network Config, System time config, Device Time Correction, and Select a plan. The 'Network Config' step is active. It contains several configuration fields: 'IP Group' (toggle), 'IP Address' (192.168.0.10), 'Subnet Mask' (255.255.255.0), 'Gateway' (192.168.0.1), 'Network Mode' (Adaptive Load Balancing), 'Major DNS' (127.0.0.53), and 'Minor DNS'. Below these is a 'Network Config' section with 'eth0' selected and a checked 'Bind static IP' checkbox. The 'MAC Address' is 00:E0:4C:68:00:0C. At the bottom left is a 'Refresh' button, and at the bottom right are 'Previous', 'Next', and 'Skip' buttons.


Click "Next" to set the system time as needed.



Click “Next” to set whether to synchronize the time zone of the added devices with the system.




Click “Next”. Then you can select the function display module in the home page.



Click “Finish” to complete the wizard setup.

2.3 Main Menu Interface Introduction



There are five parts in the main menu interface. The descriptions of each part are as shown below.

Menu Bar

No.	Description	No.	Description
1	Menu Bar	4	Status Bar
2	Tab Bar	5	Alarm Information Bar
3	Functional Areas		

Tab Bar

Menu	Description
	"Video preview"
	Including "Switch User", "Register", "About", "Switch Plan", "Modify Password" and "Clear Cache Memory"
	Click to lock the operation page. Click "Unlock" and then enter the login password to unlock it.

Functional area


Menu	Description
Video preview	To view live images and to record, snapshot and talk, etc.
Record & Playback	To remotely play the local records or back up records.
Search	Including image search by face, face comparison retrieval, license plate comparison retrieval, smart snapshot retrieval and visitor record search.
E-Map	To manage and display maps, hot spots, etc.
TV Wall Management	To set TV wall and decoding videos on TV Walls

Group Management	To manage people and assign the access permission
Data Dashboard	Smart display video window, device status, face comparison, human body temperature screening, E-map, etc.
Parking Lot Management	To manage vehicles in the parking lot
Face Greeting	To welcome visitors based on face recognition technology
Face Attendance	To help to manage staff attendance based on face recognition technology
Face Access Control	To control people entry via access control panels
Visitor List	To manage visitors and search the records of visitors.
Target Counting	To monitor and analyze people/vehicle flow in real time
Body Temperature Measurement	To view the statistics of body temperature
Industrial Temperature Measurement	To view the real-time video, analyze data and search records.
Resource Management	To add, modify or delete areas, devices or servers.
User Management	To add, modify or delete user account and set permissions for these accounts.
Alarm Center	To set alarm linkage and schedule; To search alarm logs.
Operation and Maintenance Management	To search, export and maintain logs; To back up or restore configuration; To display device/server/record status
Configuration	To set record path, snapshot path, system startup and maintenance, overload, alarm view, etc.

Favorites:


You can move the module which has a high using frequency to Favorites.

Place the cursor on the module you want to move to Favorites, and then a pentagram icon () will be displayed on the top right corner of the module. Click this icon to move. In the Favorites display area, click  to make the module return to its original place.



Wizard Settings:

On the bottom right corner of the functional area, click  to show the following wizard guide.



Other buttons:

Button	Description
	Click to shut down or reboot your device.
	Click it to add the video preview page.
	When the tab pages exceed the applicable numbers, this icon will display. Click it to view the hidden tabs.


Common buttons:

Button	Description
	Click it to edit the item.
	Click it to delete the item.
	Check the camera and then click it to select
	Check the camera and then click it to remove
	Click it to add all cameras
	Click it to remove all selected cameras

3 Device Management

3.1 Add Encoding Device

In the main menu interface, click “Add, Edit or Delete Device” to go to the following interface as shown below.



In the encoding device interface, you can view the activated device or inactivate device. Click the “Activate” tab to sort.

Activation: click “Not activated” and then enter the password of the IPC according to the tip in the pop-up activation box. After successful activation, the IPC can be connected normally.

Batch Activation: check the inactivate devices and then click [Activate] to enter the password of the IPCs in the pop-up activation box. After successful activation, these IPCs can be connected normally.

Then click “Add” to add devices. You can add multiply devices in this interface, such as face detection IPC, face recognition IPC/NVR, face recognition terminal, active deterrence IPC, LPR camera, etc.

3.1.1 Quickly Add

Click [Refresh] to quickly search devices in the same local network as shown below. Check the device and allocate the transfer server, storage server, area for it. After that, click [OK].

Click “Default password” to set the default username and password of the devices. The default username of the standard device is “admin” and the default password of the standard device is “1234”.

Note:

- * The default media transfer server and storage server can be selected when adding devices.
- * Area must be set up before adding devices. Click [Create Area] to create an area (See Area Setting).

3.1.2 Manually Add

IP Address/IP Range/Domain Name/Serial No./URL/IPV6	Protocol	Port	User Name	Password	Test
IP Address:0.0.0.0	Speco	6036	admin	••••	

- ① Enter IP address/IP range/domain name, username and password and choose protocol type.
- ② Click [Test] to test whether the device is connected successfully or not.
- ③ Select transfer server, storage server and area and then click [OK].

Devices can be added in batch by adding IP range.

If “URL” is selected, you shall add the device via RTSP protocol. Enter the URL, username and password of the device and then click [Test] to test whether the device is connected successfully or not.

IP Address/IP Range/Domain Name/Serial No./URL/IPV6	Protocol	Port	User Name	Password	Test
URL: ip:port profile1	RTSP	--			

How to get a URL?

Take one of our IPC as an example. Log in to the web client of the IPC and then go to “Config”→ “Network”→ “RTSP” interface to configure RTSP.


The default RTSP port is 554 and the URL format is “rtsp://IP or domain name:port/profile1”. For example:

rtsp://192.168.1.1:554/profile1. Profile1 stands for main stream; profile2 stands for sub stream; profile3 stands for the third stream.


For the URL of a device from other companies, please consult their technical documentation.

3.1.3 Auto Report

Select the “Auto Report” Tab to see the following interface.



- ① Enter the device ID set in the DVR/NVR or IP camera and choose the protocol.
 - If the DVR/NVR is needed to add, please go to Network→Platform Access interface of the DVR/NVR. Check “Enable”, enter the IP address and port (default 2009) of the SPECO BLUE VMS and then set the device number of the DVR/NVR.
 - If the IP camera is needed to add, please go to Network → Ports/Connections of the IP camera. Check the box next to “Enable”, enter the IP address and port (default 2009) of the SPECO BLUE VMS and then set the device number of the IP camera.



- ② Select the transfer server, storage server, area and then click [OK].

3.1.4 Quickly Add Auto Report Device

For the auto report devices, you can go to the “Unbound Auto Report Device” interface to add them quickly.

Note: please fill out the auto report information in the NVR/IPC in advance and then the device information can be searched in the “Unbound Auto Report Device” interface.

3.2 Modify or Delete Device

After devices are added successfully, they will be listed as below.

Add, Edit or Delete Device		Device Setting	Area Setting	Channel Group Setting	Task
<input type="checkbox"/> Add <input type="checkbox"/> Delete Import/Export Change Area Upgrade Save Form		<input type="checkbox"/>	No.	Edit	Device Name Type Channel Number Alarm In Number Ala
Encoding Device (Online/Total number: 1/1)		<input type="checkbox"/>	1		Device Name Speco 4 19
Decoder (Online/Total number: 0/0)					

The device channel number, alarm status, online status and record status can be viewed from the above table. Click to modify the device information; Click to delete the added device. Select the desired devices and click [Delete] to delete multiple devices simultaneously.

3.3 Device Area Selection

Select one or more encoding devices and then click [Change Area] to modify the area of the selected devices.

Add, Edit or Delete Device		Device Setting	Area Setting	Channel Group Setting	Task
<input type="checkbox"/> Add <input type="checkbox"/> Delete Import/Export Change Area Upgrade Save Form		<input type="checkbox"/>	No.	Edit	Device Name Type Channel Number
Encoding Device (Online/Total number: 1/1)		<input type="checkbox"/>	1		Device Name Speco 4

3.4 Batch Import/Export

You can import multiple encoding devices (NVR/IPC) in different local network at a time. The setting steps are as follows:

1. Create an Excel file and then edit the device information as follows. Please copy the text of the first line.

A	B	C	D	E
ip	port	protocol	userName	password
xxx.xxx.xxx.xxx	6036/9008/80/554	ipv4/sn/ipv6/domain/id/onvif/xxx		xxxxxx


Protocol: three protocols can be used here, including “ipc”, “standard device” and “NVR”.

2. Save the file as “.csv” or “.xlsx”.
3. Click Home→Resource Management→Add, Edit or Delete Device. Then click [Import/Export] to show a drop-down list. Click [Import] to import the file.

Add, Edit or Delete Device		Device Setting	Area Setting	Channel Group Setting	Task
<input type="checkbox"/> Add <input type="checkbox"/> Delete Import/Export Change Area		<input type="checkbox"/>	No.	Edit	Device Name Type Channel Number Alarm In Number Ala
Encoding Device (Online/Total number: 1/1)		<input type="checkbox"/>	1		Device Name Speco 4 19


Import
 Batch export
 Export Template(.xlsx)
 Export Template(.csv)

Export encoding devices: check the device you want to export and then click [Save Form] to export the device list.



3.5 Device Upgrade


In the “Add, Edit or Delete Device” interface, check the devices you want to upgrade and then click [Upgrade]. Select the upgrade type as needed.



Note: When multiple devices are upgraded simultaneously, the selected devices must be the same series.

3.6 Device Setting


Go to Home→Device Setting interface as shown below. In this interface, the parameters of the device can be set up.



Different devices have different menus. Please configure the device according to the corresponding user manual.

3.7 Area Setting

Go to Home→Area Setting interface as shown below.



Click [Add] to go to Area adding interface. Enter area name to create parent area. Then click [OK] to save the settings. To create sub area, click [Add], choose the parent area, enter the area name and click [OK].

3.8 Server Settings

- **Add Storage Server**

Storage server is in charge of the storage of record information, including the information of schedule record, record based on motion alarm, sensor alarm, smart detection alarm (like object removal detection, line crossing detection, etc.), responding to the search and playback of all storage data. It also supports self-defined storage path settings and IP-SAN access.

Note: If the device is logged in under server mode, you can only add one storage server. If the device is logged in under client mode, please add storage servers according to the performance of the connected management server.

If you want to add a storage server, please follow the directions as below.

1. Click Home→Add, Edit or Delete Device→Storage Server.



2. Click [Add] to go to storage server adding interface. Users can quickly add or manually add storage servers.
3. Select the “Quickly Add” tab and click [Refresh] to quickly search servers in the same local network. Check the desired servers and click [OK] to save the settings.

Select the “Manually Add” tab to go to the storage server adding interface. Enter the server name, IP address and port and click [OK] to save the settings.


When adding the storage server, you can select it as a hot spare server. Once the host server is offline, the spare server will take over.

After the storage server is added, click  to set record partition or disk.

If you have added a hot spare server, it will work as follows.


1. When the storage server of the device is offline and the offline time exceeds the predefined service fault time, the recorded file of the device will be saved by the online hot spare server.
2. When the original storage server of the device is online again and the online time exceeds the predefined server fault time, the recorded file of the device will be saved by the original storage server.

To set the server fault determination time, please go to Home→ Configuration→System Configuration interface to set.



3.9 Channel Group Settings


Go to Home→Resource Management→ Channel Group Setting interface as shown below.



- ① Click [Add].
- ② Enter channel group name, channel group and select the dwell time.
- ③ Select the parent channel group.
- ④ Add channels to the channel group. Check the desired channels and click > to add channels; choose the selected channel and click < to remove those channels; Click >> to add all channels; click << to remove all selected channels. You can also enter the key words to search the channels and then select them.
- ⑤ Click [Ok] to save the settings.

3.10 Task Management

Set the face capture source, schedule and applicable scenario.



Face Capture by IPC: it is applicable to the face detection camera.

Face Match by IPC: it is applicable to the face recognition camera.

Note: Face recognition NVR, Temperature Reading Panel, Thermal network camera and IPC without face detection function cannot set task

here.

More parameters about face comparison can be set by clicking [More Settings].

The screenshot shows a configuration window titled "Face Comparison Alarm". At the top, there are five radio button options: "Block List", "Stranger", "Visitor", "VIP", and "Allow List". Below this is a "Similarity" section with a slider labeled "Similarity(%)" set to 75. The "Intelligent Server Setting" section has a checked checkbox for "Enable Face Detection of the Face Recognition IPC". The "Send Captured Pictures to FTP" section has an "Enable" toggle switch that is currently turned off. Below the toggle are three input fields: "FTP Server Address", "FTP Server Port" (with the value 21), and "FTP File Path" (with the value /). There is also a checked checkbox for "Anonymous". An "Apply" button is located at the bottom left of the window.

Face Comparison Alarm: Select face comparison alarm list. For example, "Allow List" is selected, when a person is detected and is successfully compared with the allow list, alarms will be triggered.

Similarity: Set the similarity of the face comparison.

Intelligent Server Setting: please check "Enable face detection of the face recognition IPC" as needed.

If checked, the intelligent server will get all face capture pictures of the IPC after you configure face comparison parameters and set the schedule for the IPC. All these face snapshots can be searched in the Search interface (Home → Search).

If unchecked, the intelligent server will only get the matched face snapshots after you configure face comparison parameters and set the schedule for the IPC. Only the face snapshots successfully matched with the face database can be searched in the Search interface (Home → Search).

FTP Settings: Send the captured pictures to FTP. Please set the corresponding parameters according to your FTP server.

4 Group Management


4.1 People Management

You can add group for three libraries—Person List, VIP List and Block List.
Here taking “Add target to person list” for example

4.1.1 Add Group

- **Add the parent group**

Go to Home→Group Management→People Management→Person List.



Click [Create] to add a group, or right click on the blank of the person list column and then the “Add” button will appear. Click it to add the group name.

Note: The added parent group name and face information under it will be synchronized to the face database of the NVR, but the sub group name will not be added to the NVR. The face information under the sub group will automatically be added to its parent group in the NVR. If the parent group fails to synchronize to the face database of the NVR, but the face information of sub group is successfully added to the NVR. Now, the face group name will be named “creation date-intelligent server IP-creation time (s)-list type-parent group name” as shown below.

No.	Group
1	2022_4_21_10.214.200.200_32 (3853)
2	2022_4_22_10.214.200.111_1 (1128)
3	2022_4_22_192.168.52.214_47_White_default(0)

Group Name in NVR

For IPC, the added face information under person list and VIP list will be automatically added to the allow/white list of the IPC. The added face information under visitor list and block list will be synchronized to the corresponding list.

- **Add the sub group:**

Put the cursor on the parent group name and then you will see the follow buttons. Click “+” to add the sub group name.




Click  to modify the group name and permission group; Click  to delete the group.

4.1.2 Add Target

You can add targets for three libraries—Person List, VIP List, Block List.

- **Add target one by one**

Select the group name and then click [Add] to add the target information



Click [Upload] and select the face image saved in the local PC. Then fill out the corresponding information and click [OK] to save.

Note: the resolution of the face image shall be less than 200KB.

If the target is added to the group of the VIP, register date and VIP level shall be fill in.

If the target you newly add has already existed in the authorized face recognition device, please delete the previous one in the authorized face recognition device in case that the successful match result cannot be pushed to the platform.

- **Batch Import**

In the above interface, click [Download template] to export an Excel template and then fill out the corresponding information in the table as shown below.


After that, create a file named "Image" and then put the face images under this file.

1. Items marked in red are required
 2. The Image should be placed in the Image folder at the same level as the file
 3. The value length of each attribute cannot exceed 64 bit
 4. If there is no Group column, the selected Group is imported by default
 5. The date format is 2020-01-01 or 2020/01/01
 6. Unlocking Mode(Face Comparison,Work ID+Password,Swiping Card,Face Comparison+Password,Face Comparison+Swiping Card,Face Comparison/Swiping Card,Face Comparison/Password/Swiping Card)

Name	Birthdate	Gender	ID Type	ID NO	Country	Province	City	Group	Work Type	Work ID	Telephone	Email Address	Card Number	Password
Tom	2023-12-25	Male	ID Card	5200000000000000000	USA		New York	IT	Engineer	011111	13500000000	123456@123.com	10110	123456

Put the image file and the personal information file into the same directory.

Click [Import]→[Excel Import]




Click [Import] and then select “Batch import” to import face pictures in bulk, but the target information must be modified manually.
 Click [Import] and then select “File import”. You can select whether to search the sub folder.

Search Subfolders: choose a folder including multiple subfolders and then all pictures in the folder and its subfolders will be imported.
 Not Search Subfolders: the pictures in the folder will be imported, but the pictures in the subfolders will not be imported.

➤ **Convert images to an Excel**

Multiple images also can be converted to an Excel. Then click “Excel Import” to add targets. The setting steps are as follows.

1. Name the face images (like David_Male_1989-01-03_Engineer_Group1), separating each field with “_”.
2. Click on “Formatting Tools” to display image conversion Tool box. Click  to select the desired images.
3. Click  respectively to set the image naming rules and content of the header.



Note:

1. The naming sequence of each image selected must be the same. Please select the image naming rules in accordance with the sequential order of the name of the image.
2. The content of the header must contain those items of the image name and can be selected in any order.
3. The content of the header must contain name and group (face database), which can be entered in the image name in advance and also can be edited in the exported Excel.

● **Modify or Delete Target**



After the target is added, click  to modify; click  to delete.

Click  to view the target list as shown below.

	Edit	Name	Birthday	Gender	ID Type	ID NO	Country	Province	City	Group	Work Type
		xyf	2023-10-16	Female	ID Card					Default Gro...	

Click “Custom” to customize the target display information.

Click “Change group” to change the group.


4.1 Vehicle Management

4.1.1 Add Vehicles


➤ Add vehicle groups for each vehicle list

Click on the right of a vehicle list (Allow List/Block List/Temporary Vehicle) to add a vehicle group under the vehicle list as shown below.

Note: If you want to add vehicle groups under a vehicle list, you must enable license plate synchronization function by clicking Configuration→Server Configuration→System Setting first.




Select the desired vehicle list or vehicle group under a vehicle list and then click [Add] to add the relevant vehicle information.



➤ Binding devices for each vehicle group

Click beside the group name to bind devices for this group. All vehicles under this group can be bound to the selected devices. After

these devices are bound to this group, the vehicles you add later will automatically bind these devices.



4.1.2 View, Modify or Delete Vehicles

After you add the vehicle, you can view, modify or delete the vehicle information as needed.

Vehicle Type	Vehicle Color	License Plate Type	Start Time	End Time	Description	Operation
Small Car	Black		2023-10-17 00:00:00	2023-10-17 00:00:00		 

Select multiple vehicles and then click the [Delete] button to delete multiple vehicle information at once.

4.1.3 Import or Export Vehicles

Click [Export Template]→Export Template(.xlsx/.csv) to export a template. Then fill out the relevant vehicle information.

Vehicle Type	Vehicle Color	License Plate Type	Start Time	End Time	Description	Operation
Small Car	Black		2023-	3-10-17 00:00:00		


After that, click [File import] to import the vehicle information. Click [Export] to export the added vehicle information.

You can also get vehicle information from license plate recognition cameras/NVRs. The setting steps are as follows.

1. Click "Obtain from Devices".
2. Select the device type.
3. Select vehicle list (Allow List/Block List/Temporary List) of the LPR camera/NVR.
4. Select a vehicle group of the platform.

5. Click  to add.

6. Click “OK” to synchronize the vehicle list of the selected device to the corresponding groups of the platform.



Note: If you want to get license plate information from devices, you must enable license plate synchronization function by clicking Configuration→Server Configuration→System Setting first.


4.2 Permission Management

Click Home→People &Vehicle Management→Permission Management to go to the following interface.


You can view the sync records or bind the camera to the group or people.

➤ Add Permission Group

In the permission group interface, click [Add] to add a permission group. Enter the name and set the schedule and devices as needed.



Click “Schedule Setting” to set the desired schedule. You can set weekly schedule and holiday schedule as needed.




Click [Add] to add a new schedule template name. Double click the schedule name to modify it. Then you can select the schedule and set it as needed.

● **Weekly Schedule:**

Set the scheduled time from Monday to Sunday for a single week. Each day is divided in one hour increments. Green means scheduled. Blank means unscheduled.

Add: Add the schedule for a special day. Drag the mouse to set the time on the timeline. Or click  to manually set the time period;

click  to add new time period.




You can copy the above time period to other days by checking the relevant days. After that, click [OK] to save the settings.

Additionally, you can also copy the time period by clicking . For example, click  in front of Sunday, Monday and Tuesday, and then drag the mouse on the timeline of one of them. After that, other days that enable  will automatically copy the set time period. You can also click  next to "Copy" and then drag the mouse on the timeline of one day, and then the other days of the week will automatically copy the set time period.

Erase: Drag the mouse on the scheduled time period to delete the set time.


Delete Schedule: Put the cursor on the schedule name and then a deletion icon will appear. Click it to delete the schedule.




● **Holiday Schedule**

Set the scheduled time for a special day, such as a holiday.

1. Click the “Holiday Schedule” tab to enter the holiday schedule page.




2. Click “Holiday Schedule Setting” to set holiday schedule. Click “Add” on the left panel to add a new holiday schedule. Enter the holiday schedule name as needed.
3. Select the holiday schedule. Click “Add” on the right panel to set date and time period.
4. Drag the mouse on the timeline to set the time period or click  to manually set the time period. Click “Clear” to clear all information of the current holiday schedule.
5. Click [OK] to save the settings.



Note: Holiday schedule takes priority over weekly schedule.

➤ **Permission Binding**


Click  to bind the group or person to the selected devices.



After the binding is complete, you can modify or delete the permission group as needed.

➤ People Sync Record Query

Click “People Sync Record Query” to view the permission binding status of each person.




After the permission binding is complete, you can click  to delete the sync record here.

Note: 1. When the device is offline, the target synchronized to it cannot be deleted. Then you can delete the synchronization records here and then delete the target.

2. The added group or person must be bound with one or more cameras, or the face comparison result will not be gotten by the platform.

➤ Vehicle Sync Record Query

Click “Vehicle Group” or “Device” to view the sync status of all vehicles under each vehicle group or device.




Note: If you want to view the vehicle sync records, you must enable license plate synchronization function by clicking Configuration → Server Configuration → System Setting first.

5 Search


5.1 Image Search by Face

1. Select a picture and picture source.
2. Set the start time and the end time.
3. Set the maximum count and similarity.
4. Click [Search].

Note: Only face recognition NVRs added to this platform support this function.




Click  to play the record in a small window.



- E-Map Track View:


Create an E-map. You can create or delete an E-map in this interface. The hot spot can be added to the E-map too.



Play Track Line: Click this button to play the track line on a map.
 Playback by Tracks: Click this button to play the track video.


5.2 Face Comparison Search

1. Go to Search → Face comparison retrieval interface.
2. Select the IPC and query method. Then select match type or target as needed.
3. Set the start and end time and then click [Search] to search the face pictures.



5.3 License Plate Comparison Search


1. Select the camera.
2. Enter the license plate and select the match type.
3. Set the start time and end time.
4. Click [Search]



5.4 Smart Snapshot Search

The snapshot results from the intelligent server and face recognition devices can be searched. You can search the snapshots of human face, human body, motor vehicle and non-motor vehicle.

For example: Search faces from intelligent server



If the snapshot type is human face, put the cursor on the captured picture and then some shortcut buttons will be displayed.




Click  to add the capture picture to the library. Select the library on the left and then fill out the information of this target. Click [OK] to add.

Put the cursor on the captured picture and then click  to quickly search images by this picture.

Put the cursor on the captured picture and then click  to quickly download the captured picture.


Search vehicles from intelligent server:



Click  to quickly skip to the playback interface and play the record.

Click  to view the snapshot details, including the original image, target picture, snapshot type, snapshot time and so on.

Select the searched pictures as shown below and click [Export] to export the selected pictures.



You can also export all searched pictures in the current page once by checking "Select Current Page" and clicking [Export].

Search vehicles from face recognition NVR:

Monitoring Point
Export

default area

Match Type

Motor Vehicle

Search Source

Face Recognition NVR

Event Type

All

License Plate

Vehicle Color: Unknown,Red,Oran

Vehicle Type: Unknown,Saloon C

Vehicle brand type

All

Time

2023-10-18 00:00:00 ~ 2023-10-18 23:59:59

Search



2023-10-18 10:27:57
Device Name_IPC



2023-10-18 10:27:48
Device Name_IPC

Total: 2 50


Click  to play back the record in a small window; click  to quickly download the captured picture.

6 Face Greeting

Face Greeting: After successful face comparison, the words/voice of welcome will be heard by the guests and their photos will be shown on the screen.

Click “Face Greeting” to go to the face greeting interface. The setting steps are as follows:


- ① Create a VIP group and add targets for this group in the VIP list interface. Then set a permission group for them. The setting details are similar to adding targets to the person list. See chapter 6 for details.




Note: The camera for face greeting must support face recognition function, such as face recognition and access control panel, face recognition camera and so on.

If the person added to the person list adds to the VIP list again, this person may be not recognized as a VIP person. Please delete this person in the person list first.

- ② Select the schedule, face match type in the Task interface (See [Task Management](#) for details).




- ③ Real-Time Monitoring. Drag the camera name to the preview window. When there are targets detected, the match result will be displayed on the right panel.




④ View the match result of the greeting screen. Click the “Display Setting” tab to set the sub screen (greeting screen).

In this interface, greeting screen background style, screen display mode, VIP box style, face greeting language and so on can be set up. Select the sub-screen display channel: if the secondary monitor is connected to the device, “+” will display in the Link Camera to Sub-screen box. Click “+” and choose the desired cameras you want to display in the sub-screen and then click [OK] to save the settings. Multiple cameras can be selected at a time.



Sub-screen display: in the real-time monitoring interface of Face Greeting, right click on the desired channel and select the sub-screen you want to display by clicking “Project onto”.



Greeting Screen Background Style: three options: Video, Background Picture and Pure Color Background

Screen Display Mode: 1/4/9/16 screen display mode can be selected.

VIP Box Style: with borders or pure image.

Welcome Broadcast or Not: if enabled, the welcome voice will be broadcasted when the VIP person is successfully recognized.

Welcome Voice Play Order: choose which one to broadcast first between welcome voice and guest name

Greeting Language: please enter the content and select the color as needed.

Max. Number of VIP Box: up to 5 boxes.


Frame Holding time: set the duration time of VIP box appearing after the captured face is matched successfully.

Loop Playback: if enabled, the VIP name will be broadcasted in a loop.

Single VIP Cycle Time: set the time of the single VIP name broadcasted.

Single VIP Box Size: set the percentage of VIP box size occupying the entire screen.


⑤ Search the face greeting records. Click “VIP Search” tab as shown below.



You can enter the key word to search the target or manually select the target from the library. Then set the start time and the end time and click “Search” to search the record. The detailed information of this target will be shown. Click to play the record.

7 Face Attendance

Click  at the bottom right corner to select “Attendance Guide” to quickly set the attendance.



In the attendance guide interface, click the corresponding menus in sequence to quickly set the attendance.

7.1 Add Devices and Targets

➤ Add Devices

In the attendance guide interface, click “Add Device” to enter the encoding device interface. Click [Add] to add the face attendance device (eg. face recognition panel).

➤ Add Targets

After the attendance device is added successfully, click  at the bottom right corner to expand the attendance guide. Click “Add Target” to go to the person list interface.



In the person list interface, add the attendance group and targets as needed. Refer to [People Management](#) for details.

Note: The compared person in attendance system shall be added in the person list in advance. One person only can be added in one group. If this person also be added in other groups (like VIP list), the attendance comparison result will not be obtained.


➤ Permission Management

Set the permission for the attendance group or targets. Refer to [Permission Management](#) for details.

7.2 Attendance Configuration

7.2.1 Attendance Check Point Settings


Select the attendance device and then click [Set Check Points]. Enter the name and remarks in the pop-up window. Then click [OK] to save the settings.



7.2.2 Attendance Period Settings

If a company has different working time for different employees, you can add different attendance rules.

Click [Add] to set the detailed attendance rule.



➤ Regular Attendance

Set the attendance period name and working time. Then click [Save] to save the settings. Click [Add] again to add next attendance period.

Basic Setup: set the normal working period.

Time Setup:

Start-work time: the normal start-work time

End-work time: the normal end-work time

Must check-in/out: "Must check in" next to the first check-in period and "Must check out" next to the last check-out period are checked by default. That is to say, in the first check-in period, the employees must check in; in the last check-out period, the employees must check out. During the period that "Must check in/out" is not checked, the employees don't check in/out, who will not be regarded as "Not check in/out" or "Absent".

Effective check-in/out time: Set the effective check-in/out period. If the employees check in/out before/after this period, the check-in/out will be invalid and will be regarded as “Not check-in/out”.

Work hours: automatically calculate according to the start-work and end-work time.

Overtime setup: there are three overtime levels. Please set as needed.

Note: The end-work time of overtime setup must be within the effective period of basic setup.

You can deduct the dinner time when counting the overtime. You can also enable “Check in for overtime working” as needed.

Deduct dinner time: if checked, the system will automatically deduct the dinner time from the overtime. The overtime level depends on the time duration after deducting the dinner time.

Flexitime:

You can enable/disable “Late arrival and early departure are allowed” or “Late arrival and late departure are allowed”.

Late check in over xx min is recorded as late: set the allowable minutes for late. If the employees check in within the period after the start-work time, the status will be “Normal”.

Early check-out xx min is recorded as leave early: set the allowable minutes for leave early. If the employees check out within the period before the end-work time, the status will be “Normal”.

For example: The start-work time is set as 09:00, and the late allowable duration is 20 minutes. If the employee checks in at 9:15, the attendance status will be “Normal”.

Late arrival and late departure: for example, the limit time is set to 30 minutes and the normal working time is 9:00~18:00. If the employee checked in at 9:30, he/she should check out at 18:30

➤ **Flexible Attendance**

Statistical methods: “Calculate records in pairs” or “calculate the first and last record”

Calculate records in pairs: Add up the time period between each two check records. The time interval of each two records must be more than 1 minute.

Calculate the first and last record: Calculate the time period between the first and last check records.

Work Hours: Set it as needed.

For the set attendance period, put the cursor on the attendance period name and then  icon will appear. Click it to modify the attendance period. Select the attendance period and click [Delete] to delete the attendance period.

7.2.3 Attendance Shift Settings

Attendance Shift: The employees shall perform their duties according to the shift schedule.

Click [Add] to set the shift name and shift schedule.

Shift cycle can be set by day, week or month. The schedule will automatically repeat according to the set day(s), week(s), month(s) or years.

Day: You can customize the attendance period of each day. The number of days should be between 1 and 31.

Week: The schedule will repeat every 7/14/21/28/35 days based on the week.

Month: You can customize the attendance period of each month.

Year: You can customize the attendance period of each year

Working overtime on days off:


You can set overtime on weekends or holidays.

Work hours: set it as needed. For example: work time is set to 8 hours, the overtime will be calculated as 8 hours even if the actual working time is more than 8 hours. If the actual working time is less than 8 hours, the overtime will be calculated according to the actual working time.

7.2.4 Personnel Scheduling

You can set different schedule for different attendance groups or employees.


Select the attendance group or employee and then click [Scheduling] to select the shift and schedule start time and end time. Finally, click [OK] to save the settings.




If the schedule for the attendance group or the employee needs to modify, select the group or person, click [Delete the scheduling] to delete the current schedule.

If there is something wrong with the attendance shift, you can select the person or group on the left and click [Scheduling] to modify.

When the temporary scheduling is needed, select the person or group, click [Temporary Scheduling], select date and period. After that, click [OK] to save the settings.



If you want to modify the temporary scheduling, you can select the person or group and click [Temporary Scheduling] to modify. Click [Delete] to delete the temporary scheduling of the day.



Select the group /person and click [Clear Temporary Scheduling] to clear all temporary scheduling of this group/person.

If you want to delete the scheduling, click  at the top right corner. Select the group or person and then click [Delete the Scheduling] to delete the scheduling.



7.2.5 Attendance Handling

If someone needs to apply for leave or correct the check-in/out record, you can enter the attendance handling interface to set up.

Leave/Business-Trip Settings:

- ① Select the employee who wants to apply for leave or do business trip.
- ② Click [Leave/Business-trip].
- ③ Select the date the employee wants to apply for leave or do business trip.
- ④ Select the type, sub type, leave time and remark.
- ⑤ Click [OK] to save the settings.



: click it to set the sub type of leave or business trip.

Correct Check in/out **Leave/Business-trip**

Search

Default Group

04

Dec 2023

Sun	Mon	Tue	Wed	Thu	Fri	Sat
26	27	28	29	30	1	2
3	4	5	6	7	8	9
10	11	12	13	14	15	16
17	18	19	20	21	22	23
24	25	26	27	28	29	30
31	1	2	3	4	5	6

Type: Leave

Sub Type: Sick Leave

Leave Time: 09:00 -- 18:00


Remark:

OK Cancel

Cancel Leave/Business-Trip:

When the leave or business-trip cancels, you can go to the attendance handling interface to cancel it.


1. Select the person you want to cancel the leave/business-trip and then a timetable will display.
2. Clicking on the Leave/business trip tag will display a Leave/business-trip detail box.
3. Move the slide bar to the right as shown below. Click to cancel this item.




Correct Check-in/out Time:

You can correct check-in/out time for the exceptional records according to actual needs. If the employee actually starts and ends his/her work in the normal working time but he or she forgets to check in/out, then “Correct Check in/out” function can be used.

1. Select the person you want to correct the check in/out record.
2. Find the desired date and then click [Correct Check in/out].
3. Correct the check- in/out time as needed.
4. Click “OK” to save the settings.




On the day that you correct check-in/out time, an icon () will appear. Click this icon to view the details.



7.2.6 Holiday Settings

You can set a special day as a holiday. The holiday here takes priority over the attendance shift. That is to say, once a day is set as a holiday, there is no need for you to check in even if it is scheduled in the working day.

In the holiday settings interface, click [Add] to add the holiday as needed.



7.2.7 Basic Configuration

In this interface, you can set the attendance accuracy.




7.3 Search Attendance Record

You can search the desired attendance records to view the employee’s attendance status by filtering the conditions, such as attendance group, name, etc.

➤ Statistics by day/month

Click “Statistics by day”, select the employee, set the time and click [Search] to view the attendance status of the employee on each day (including late, early leave, absent, overtime, etc.)



Click [export] to export an Excel of the attendance result. These exporting items can be customized as needed.

Click "Statistics by month", select the employee, set the time and click [Search] to view the attendance status of the employee in each month (including late, early leave, absent, overtime, etc.)

➤ **Attendance Record**

In this interface, you can search the attendance by temperature and mask-wearing status.

➤ **Export Reports**

In the statistical reports interface, you can generate Excel daily/monthly/abnormal attendance report and export them to the USB flash drive.

➤ **Send Reports Regularly**

You can regularly send the statistical report to the designated email address. The setting steps are as follows.


Click "Send reports regularly" and go to its setting interface. Click [Add] to fill out the report type, employee, delivery date, send time, mail title, text and recipient.

Note: At the sending time point, the authentication server (management server) must be online and connected by a monitor client.

Report type: daily report, monthly report and abnormal attendance report.

Delivery Date: Daily report: next day; Monthly report/abnormal attendance report: the first day or the last day of each month

Recipient: The email address of recipient must be added in the person list (Group management → Person List) as shown below. In addition, the email address of the sender has been set in the email settings interface. Please see Email Settings for details.



➤ **Search Attendance Log**

Operator	Object Type	Target Object	Operation Type	Time
admin	Correct Check-in/out	04	Add	2023-12-23 16:05:27
admin	Correct Check-in/out	04	Delete	2023-12-23 16:05:14
admin	Correct Check-in/out	04	Add	2023-12-23 16:04:42
admin	Leave/Business-trip	04	Add	2023-12-23 16:02:53
	Attendance Shift	two days off	Add	2023-12-21 10:57:16
	Attendance Shift	One day and two days of...	Add	2023-12-21 10:57:16


7.4 Statistics of Attendance Data

In the statistics interface of Face Attendance, you can view the attendance data in the form of chart.

Granularity: Group or human can be selected. If Group is selected, the attendance data of each group (department) can be viewed.

If Human is selected, the attendance data of the employees in the group (department) can be viewed.

You can quickly view the attendance data by week/month/year and also can view the attendance data in a specified period.



7.5 Real-time Monitoring

7.5.1 Real-time Monitoring

Go to Face Attendance → Real-Time Monitoring interface. Face comparison information can be viewed after the camera is dragged to the preview window.

Note: The compared person in attendance system shall be added in the person list in advance. One person only can be added in one group. If this person also be added in other groups (like VIP list), the comparison result will not be obtained.

The screenshot displays the 'Monitoring Point' interface with a central camera feed of a hallway. On the right, the 'Attendance Overview' panel shows:

- Lib Name: All
- Auto Refresh Interval: 30 mins
- Actually/Should Arrive: No Data (0/0)
- The arrival status of subordinate departments: No Data
- Comparison List:
 - Allow List: IPC, 12-23 16:15:04, 92%

Attendance overview: you can view the number of people who should arrive or actually arrive.


7.5.2 Data Synchronization

When the attendance device/transfer server/intelligent server is offline within a short time, there are attendance data generated during this time. After the above-mentioned device or server is online, click  at the top right corner of the camera deployment interface and then the synchronizing task will be triggered. Up to 6-hour offline time are supported for the attendance device. So, the system will synchronize the attendance data within 6-hour time to the platform after the device is online

Note: The attendance device must support synchronization function, or this function cannot be used.

8 Face Access Control

Click  at the bottom right corner to select face access control guide.




In the face access control guide interface, click the corresponding menus in sequence to quickly set the face access guide.

8.1 Add Face Recognition & Access Control Device


Go to Resource Management → Add, Edit or Delete Device → Encoding Device interface. Then click [Add] to add the face recognition & Access Control device.

After the face recognition & access control device is added, please enter the device setting interface to configure tamper alarm, door contact configuration, door lock and wiegand configuration (varies by models).




8.2 Permission Settings

Go to the permission management interface. Add a new permission group or add the face recognition & access control device to the added permission group.



8.3 Event Linkage


In the event linkage interface, you can set alarm linkage items for anti-tampering alarm or door contact alarm



8.4 Record Search

1. Pass Record

In the record search interface, you can search the pass records by time, type and device.



Select the “Stranger” type. Click [Add to library] to add the stranger to the face database.

Click [Export] or [Export All] to export the Excel pass records.


(2) Incoming Call record

In the incoming call record interface, you can search the call record between the monitor client and the device.


9 Video Preview

9.1 Video Preview

Go to Home→Video Preview interface as shown below.



The descriptions of the video preview buttons are as follows.



Button	Description	Button	Description
1	Screen display mode; click  to view more screen display modes. Please select as needed.	6	Show/hide target tracking box
2	Full screen	7	Close all previews
3	Enable/disable OSD	8	Save the current view mode
4	Enable/disable broadcast	9	Export snapshots
5	Manual alarm output		

4:3/16:9/Original Aspect Ratio/Full-Win: window display ratio, please select it as needed.

Toolbar on the display window:

Button	Description	Button	Description
	Close image		3D zoom in
	Start/stop recording		Zoom in
	Snapshot		Zoom out
	Enable/disable audio		Fit to window
	Enable/disable talkback		Manual alarm output
	Enable/disable channel talkback		Monitoring point setting (camera setting)
	PTZ control		

When the IPC under the DVR/NVR device has access to the channel, click  to enable two-way audio between the DVR/NVR and the monitor client; click  to enable two-way audio between the IPC and the monitor client.

Right-click button function:

Menu	Description	Menu	Description
Close Channel	Close image	Start Channel Talkback	Enable/disable two-way audio between the channel and the monitor client
Start Record	Start/stop recording	Channel Info.	Display channel name, IP address and the current stream
Instant Playback	Click it to play back immediately	Stream	Choose video stream
Audio ON	Enable/disable audio	Full Screen	Display image in full screen
PTZ Control	Click it to show PTZ control panel	Image Adjustment	Set the image's brightness, saturation, contrast and so on
Snapshot	Capture images	Manual Alarm Out	Click it to select alarm output device and then trigger alarm out manually
Start Talkback	Enable/disable two-way audio between the device (eg. NVR) and the monitor client		


4:3/16:9/Original Size/Full Screen: screen display proportion; please select it as needed.

Note: the platform only can enable audio of one window. If the audio is enabled in one window, the audio in previous window will be disabled.

9.1.1 Monitoring Point View

- **Start View**

To start video preview, please drag cameras from the list to the right display window or select a window and then double click the camera. The image can be dragged to any window at random.




● **Stop View**

- ① Place the cursor on the video preview window to display the menu toolbar and then click  to stop viewing.
- ② Right click on the video preview window and then select “Close Channel” to stop viewing.
- ③ Click  on the toolbar of the video preview interface to stop all videos.

9.1.2 Channel Group View

➤ **Channel Group Setting**


- ① Go to Home → Channel Group Setting interface as shown below.



- ② Click [Add].
- ③ Enter channel group name, channel group and dwell time.
- ④ Select the parent channel group.
- ⑤ Add channels to the channel group. Check the desired channels and click  to add channels; choose the selected channel and click  to remove those channels; Click  to add all channels; click  to remove all selected channels. You can also enter the key words to search the channels and then select them.
- ⑥ Click [Ok] to save the settings.


➤ **Start Channel Group View**

After the channel group is set successfully (See Channel Group Setting), go to video preview interface as shown below.



You can start the channel group view as follows.


1. Choose the screen display mode according to the channel number of the channel group. Select a window and then double click the channel group name to play all channels in the group.
2. In the current screen display mode, select a window and then click  beside the channel group name to play all channels of the channel group in this window in sequence. (Put the cursor on the channel group name to display )
If there is only one sub channel group under the parent group, select a window and then click  next to the parent group name to play all channels in the parent group and the sub channel group in the window in sequence.
Select a window and click  next to the sub channel group to play all channels of the sub channel group in this window in sequence.
3. If there are several sub channel groups under the parent channel group, click  next to the parent group name and then all sub channel groups will play in sequence. The screen display mode will automatically adapt to the channels of the sub group.



Click  to play the previous sub channel group; click  to play next sub channel group; click  to stop auto switch among the sub channel groups.

➤ **Stop Channel Group View**


- ① Place the cursor on the auto-switch window and then click  to stop viewing.
- ② Right click the auto-switch window and then click “Close Channel” to stop viewing.
- ③ Click  on the toolbar of the live view interface to stop all live view.



9.2 Smart View

In the live view interface, click  on the right of the interface. A menu bar will be shown on the interface as shown below. Then you can switch the preview mode between video preview and smart viewing mode.

Note:  : it is a smart mode icon but not a functional button. You must click the smart display button under it to show the corresponding results.



The descriptions of the button on the right:

Menu	Description	Menu	Description
	Preview only mode		Smart mode icon
	Smart Snapshot: real-time display of snapshots, including face, human body, motor vehicle, non-motor vehicle and vehicle plate.		Face Comparison: Real-time display of face comparison results




9.2.1 Face Comparison

If it is the first use of face comparison function, please configure it in the following order.


Add face comparison device → **Create a group** → **Add targets to the group** → **Set task** → **Real-time View** → **Search faces**

1. Go to Home → Resource Management → Add, Edit or Delete Device interface to add face recognition devices.
2. Create a group, add targets to the group and bind permission for them. Please refer to [Group Management](#) for details.
3. Set the task for these added face comparison device. Refer to [Task Management](#) for details.
4. For the added NVR with face recognition function please set the face comparison parameters by entering Resource Management → Device Setting interface. Refer to the following interface.




Please select “Successful Recognition” or “Stranger” as needed and then set the schedule separately. After that, check the group and set the similarity. Finally, save the settings by clicking [Apply].

If the face comparison settings cannot be set according to the above-mentioned way, you can log in the web client of the NVR and then configure face recognition to realize the auto report of the face match result as shown below.




Additionally, please make sure the face detection function is enabled for the AI IPC (click Device Setting → Face Detection).



● **View the real-time snapshot and comparison result**

Face capture results can be pushed by the cameras with face detection function. Human body/motor vehicle/non-motor vehicle capture results can be pushed by the cameras with human/vehicle classification function. Face Comparison and license plate comparison result can be pushed after the face/license plate comparison is configured, even if the corresponding cameras are not playing in the live view interface.



In the smart snapshot area, click the corresponding icon (face/human body/motor vehicle/non-motor vehicle/plate) to filter the display of smart snapshots. Disable the selection and then the corresponding smart snapshots will not be displayed. Click  button to quickly go to the smart snapshot retrieval interface.



For attribute display settings, please refer to snapshot attribute settings for details.

Note: If you want to view the detailed attribute/feature information of the snapshot images, you should add the AI IPC with video metadata

function and this function must be enabled first.

Quickly adding the detected target to the face database:

Put the cursor on the face snapshot and then click +. The following window will pop up. Select the group and then fill out the relevant information to add.




Click  to quickly skip to the image search by image interface.

The captured picture can be exported. Click  and then select the export path and then click [OK] to export

● Face Comparison Display Settings


Click  on the right corner of the live interface to display the configuration window as shown below. One or more items can be selected.

Pop-up prompt: if enabled, the alarm box of the corresponding face comparison result will pop up. If disabled, the alarm box will not pop up.




Frame Holding Time: select the alarm pop-up window holding time as needed.

Statistics display: If selected, the corresponding statistical information will displayed on the top of the preview window.




- **Face Comparison Records**

Click  to view the face comparison details. Click  to quickly add the captured face picture to the face database.



Click  to quickly enter the face comparison retrieval interface. Select the camera and click [Search] to search the face comparison results.




9.2.2 License Plate Comparison


If this is the first time for you to set the license plate recognition function, please follow the procedures.

Enter Group Management → People & Vehicle Management → Vehicle Registration → Add Vehicles → Task Settings → View Real-time License Plate Comparison Results → Search License Plate Comparison Result

1. Go to People & Vehicle Management → Vehicle Registration interface. Click [Add] to add the vehicle information to Allow List or Block List.




2. Click the “Task” tab to setting license plate recognition task. Select the license plate recognition camera and then click applicable scenario. Select “Vehicle deployment control” and click “OK”.



3. Ensure that the license plate recognition IPC has already enabled the license plate detection function.


● **License Plate Capture and Comparison Settings**

Pop-up prompt: if enabled, the alarm box of the corresponding license plate comparison result will pop up. If disabled, the alarm box will not pop up.




Frame Holding Time: select the alarm pop-up window holding time as needed.

Statistics display: If selected, the corresponding statistical information will displayed on the top of the preview window.



- **License Plate Capture Records**

Click  to view the license plate capture details.




Click  to quickly go to the record playback interface.

Note: if you don't set the record schedule or record linkage is not configured for the corresponding events, no record will be searched after you enter the record playback interface.

- **License Plate Comparison Records**


Click  to view the license plate comparison details.



Click  to quickly enter the vehicle plate comparison interface. You can search the captured vehicle plate as needed.

9.3 Plan View

In the video preview interface, select “View” on the left menu bar.



- **Add View Plan:**


- ① Right click “Video Preview 1” and then select “Create View” or click  to add a new view plan. Clicking “Create View” to prompt an adding view window. Enter the view name and click [OK] to set view plan.
- ② Select screen display mode and then drag monitoring points or channel group to each window.
- ③ Click “View” on the left menu and then right click the newly added view name. Select “Save View” on the pop-up menu to save the view plan or click  on the live view interface to save the view plan. Double click view name to call the view plan.

- **Modify or Delete View Plan**

Select the added view and then right click to prompt a pop-up window. Select “Modify View” or “Delete View” to modify or delete the view plan.

- **Start/stop auto-switch**


If multiple view plans saved, you can play these views in sequence.



Enter the dwell time (5~3600s) and then click [Start auto-switch] to play these views in sequence. Click  to view the previous view; click  to view next view; click  to pause.

9.4 PTZ Control


Click  or right click to select "PTZ Control" to enter PTZ control interface. The directions of PTZ, zoom, focus, Iris, preset, trace and cruise can be controlled through PTZ control panel.



 : Preset;  : Cruise;  : Trace

9.5 Instant Playback

In the video preview interface, right click on a playing channel to select “Instant Playback” and then set the playback time to play the record instantly (the record of the channel in the past five minutes will be searched and played from that time when the record exists).




10 Record & Playback

10.1 Record Configuration

This device supports many recording types, such as manual recording, schedule recording, motion alarm recording, smart alarm recording, etc.

10.1.1 Schedule Recording

Go to Home→“Record Setting”.



The screenshot shows the 'Record Setting' interface with a table of schedule settings. The table has columns for Channel Name, Stream Type, Record Schedule, Audio, Recording Before Alarm(s), After Alarm Time(s), Expire Time(day), and Offline Record. The table lists six channels, all with a 'Main Stream' type and a '7*24' schedule. The 'Recording Before Alarm(s)' and 'After Alarm Time(s)' values are 0 and 60, respectively. The 'Expire Time(day)' is 'Never Expire' and 'Offline Record' is 'Open' for all channels.

Channel Name	Stream Type	Record Schedule	Audio	Recording Before Alarm(s)	After Alarm Time(s)	Expire Time(day)	Offline Record
*Device Name_IPC	Main Stream	7*24	Open	0	60	Never Expire	Open
*Device Name_IPC	Main Stream	7*24	Open	0	60	Never Expire	Open
*Device Name_IP Camera01	Main Stream	7*24	Open	0	60	Never Expire	Open
*Device Name_IP Camera03	Main Stream	7*24	Open	0	60	Never Expire	Open
*Device Name_Camera01	Main Stream	7*24	Open	0	60	Never Expire	Open
*Device Name_IPC	Main Stream	7*24	Open	0	60	Never Expire	Open

To set schedule recording, select the channel, stream type and schedule. Then Click [Apply] to save the settings.

Recording Before Alarm: set the time to record before the actual recording begins.

After Alarm Time: set the time to record after the actual recording is finished.

Expire Time: set the expiration time for recorded video. If the set date is overdue, the recorded data will be deleted automatically.


Offline Record: When the IPC/NVR is disconnected with the storage server, the IPC/NVR starts offline record. After the network is connected again, the offline record of IPC/NVR stored on the SD card or HDDs will automatically transfer to the storage server.

Note:


1. The time of the IPC/NVR must be the same as the storage server.
2. A maximum of 8 channels can simultaneously transfer the offline records to the storage server.
3. Due to the limit of the storage capacity, the previous records of the IPC may be overwritten if the disconnection time is too long so that only a part of records can be replenished.
4. Only support the most recent 12-hour record replenishment.

● To set schedule:

- ① Click the “Schedule Setting” tab to go to the following interface.




- ② Click [Add].



- ③ Enter the schedule name.
- ④ Set the schedule. Drag the mouse on the timeline to add or erase the time period. Click  to manually set the time period. Put the cursor on the set schedule name and then a deletion icon will appear. Click it to delete the schedule.

10.1.2 Alarm Linkage Recording

- ① Go to Home → Device Setting interface. Select the desired device to enable the alarm event and set schedule.
- ② Go to Home → Alarm Center → Alarm Linkage as shown below. Select alarm type, enable record, set linkage channel and set the schedule.
- ③ Click [Apply] to save the settings.




10.2 Playback

In the main menu interface, click “Record Playback” to go to record playback interface. Record files saved on the HDD/ SD card of the devices and storage server can be played.

There are three types of playback: normal playback, smart playback by face, smart playback by license plate.

10.2.1 Normal Playback




Area Description

Area	Description	Area	Description
1	Playback area	3	Record timetable area
2	Toolbar	4	Time and event search area; resource area

Toolbar on Playback Window

Button	Description	Button	Description
	Stop viewing		Zoom in
	Audio on/off		Zoom out
	Snapshot		Fit to window

Button Descriptions of Area 2:

Button	Description
	Screen display mode button.
	Full screen
	Close all window viewing
	Rewind
	Low speed playback
	Stop
	Play/Pause
	Next frame. In the playback mode, click the pause button and then click this button to play frame by frame.
	Click it to select playback speed.
	Click it to restore normal playback
	Forward 30s or backward 30s
	Set backup time
	Start backup
	Synchronous playback or asynchronous playback

Clip and backup:

Click  to enter the edition status. On the recorded timescale, select the start and the end time or right click on the timescale and then select [Change backup time] to set the backup start time and end time. After that, click  to enter the record backup interface to view the backup file list.



The screenshot shows the 'Record Backup' interface. At the top, there are tabs for 'Record Backup', 'Search Picture', and 'Record Setting'. Below the tabs is a 'Backup' section with a timescale from 00:00:00 to 10:19:00:00. The timescale has markers every 2 hours. Below the timescale are several colored buttons: Manual (orange), Schedule (blue), Video Detection (green), Motion Detection (yellow), Sensor (red), Face Event (cyan), Target Counting (magenta), Behavior Analysis (teal), and POS (purple). There are also buttons for 'Record Backup' and 'Backup on Dev'. Below these are buttons for 'Start All', 'Pause All', 'Stop All', and 'Clear All Finished Tasks'. At the bottom, there is a table with the following data:

No.	Channel	Start Time	End Time	Duration	Progress	Operation	Backup Path
1	Device Name_Camera01	2023-10-18 16:33:43	2023-10-18 17:02:29	00:28:46	3%	 	C:\backup\Device_Name_Ca...

Right-click button menu

Menu	Description	Menu	Description
Close	Close viewing	Zoom out	Zoom out the current image
Audio On/Off	Audio on/off	Full Screen	Click to enter full screen mode
Snapshot	Snapshot	Sub stream	Switch to sub stream playing
Zoom In	Zoom in the current image		

Other buttons

Button	Description	Button	Description
	Add tag		Event list
	Backup		

Set record date, record type (for some devices, “Main Stream” can be selected to play the record, or the record will be played by sub stream if unselected) and the record playback source in the playback interface. Drag the camera on the right side to playback window for playing or double click a desired channel to play or click [Search] to search the record files and then click [Play] to play.

Playback record type includes manual recording, motion detection recording, schedule recording, sensor recording, target counting recording and behavior analysis and so on.

In the timetable, different color bars stand for different record types. For instance, yellow bar stands for motion recording data; blue bar stands for schedule recording data; red bar stands for sensor record data, etc.

The time scale can be zoomed in by clicking  and the time scale can be zoomed out by clicking . The time scale can be restored to 24 hours by clicking . When the time scale is zoomed in, drag the timeline to see the time spots.

Synchronous Playback: in a certain time, all channels playback its record at the same time together; if one channel has no record data at this time, this channel will wait.

Click  on the toolbar in the playback interface to go to the synchronous playback interface.

In synchronous mode, one camera can only have one playing window. All cameras’ record information can be viewed at the same time.


When playing record file in synchronous mode or asynchronous mode, clicking  or  will be useless unless all the playback windows are closed.

Asynchronous Playback: when playing some channels’ record at the same time, each channel is independent from the others and each channel’s playback time is different.

Click  to go to the asynchronous playback interface. Please play the record according to the ways introduced as the above. The record bar in asynchronous mode is as below.

10.2.2 Smart Playback by Face

For the added face recognition NVR, you can play back by searching face.



Clicking on **Face** enters the above interface. Select the face recognition NVR and then click “Upload” to add a face picture. You can add the face picture from the USB flash drive, target picture or group. After that set the start and end time, max. number and similarity and then click [Search] to search the records.

Add a face picture from the USB flash drive: Click “Upload” to select the desired face picture in the USB flash drive and then click [OK] to save the settings.


Add a face picture from the target picture: Select cameras, search resource, query method and time to search targets. Then select the target and click [OK].

Add a face from the face database:

1. Click the “Group” tab.
2. Select the face picture from the person list.
3. Click [OK] to save the settings.

The picture must be added to the corresponding list in advance, or no picture can be searched. Refer to Chapter 6 Group Management for details.


Note: The record source is from the HDD of the face recognition NVR. The comparison record of this person must exist in the HDD, or no record can be played.



10.2.3 Smart Playback by License Plate

The vehicle records can be searched from the NVR. The setting steps are as follows:


1. Select the NVR.
2. Enter the license plate number to select the plate from vehicle database of NVR.




Network device: select the record source from the NVR.

10.2.4 Playback by Time

- ① Go to Home → By Time interface.
- ② Select channel (or monitoring point), set the start time and the end time, select the playback source and then click [Search].



- ③ Click  to play the record.



Click  button on the top right corner to play in full screen mode.

Double click the image to switch to slice search mode by hour.

Double click an image to switch to slice search mode by 5 minutes. Click “Slice Per Day” or search it again to return to slice search mode by day.

Record Backup: The selected time slice will be quickly backed up by clicking the “Record backup” tab next to “Slice Per Day”.

To Storage Playback: The selected time slice will be quickly played back in the storage playback interface by clicking this button.

10.2.5 Playback by Event

- ① Go to Home → By Event interface.
- ② Select the desired monitoring point, set the record source, the start time and the end time and then check events.


③ Click [Search]. The searched record data will be listed. Click [To Storage Playback] to play the record in the storage playback interface;

click  to play the record in a small playback window; click  to back up the record data.

10.2.6 Playback by Tag


Note: Record tag cannot be added to the record from the device.

- ① Go to Home → Record Playback interface.
- ② Select a channel and put the cursor on the right center. Then a tag icon () will appear. Click this icon to add tag.
- ③ Go to Home → By Tag interface. Select the start time and click [Refresh] to search the added tags.
- ④ Click  in the playback column to play the record.



10.3 Record Backup

In the main menu interface, click “Record Backup” to go to the backup interface. The setting steps are as follows:



- ① Select the desired monitoring point.
- ② Get records from device or storage server.
- ③ Select date and event type.


- ④ Drag the mouse on the recorded time period to set the start time and the end time of backup. Then click [Record Backup].
- ⑤ The backup progress will be seen during backing up the record. Click  to pause; click  to stop backing up the record; Additionally, you can start/pause/stop all backup tasks or clear all finished tasks in this interface.

“Backup on device”: This function is applied to the added NVR devices. Search the record from the HDD of the NVR in this interface and then insert a USB storage device into the USB port of the NVR and then click this button. Then the recorded files will be backed up to the USB storage device remotely.

10.4 Search Picture

In this interface, pictures stored on the SD card/HDD or storage server can be searched and viewed.

These snapshots saved on the storage server or SD card /HDD must be triggered by alarm events so that they can be searched.



1. Select the device and playback source.
2. Set the start time and the end time.
3. Click [Search]

Click the searched picture to zoom in. Click it again to return to its original size. Check the selected picture and click “Export” to export the selected pictures.

11 Alarm Management


11.1 Alarm Server Configuration

Alarm server is in charge of receiving and recording alarm information of connected devices and then sending the alarm information to the relevant user terminal system or devices in accordance with prior alarm settings. There is a default alarm server.

Go to Home→Add, Edit or Delete Device →Alarm Server interface to view the online status of the alarm server. If it is not online, please check its network connection.


11.2 Alarm Configuration

① Go to Home→Device Setting interface.



Select the desired device to enable alarms (refer to the user manual of the corresponding device for the detailed settings).

② Go to Home→Alarm Center→Alarm Linkage interface.



Select area, alarm type and then enable alarm linkages.


All ON: enable all alarm linkages of the current alarm type and area (schedule excluded).

All OFF: disable all alarm linkages of the current alarm type and area (schedule excluded).


Select beside the device name and select "ON" to enable all alarm linkages of the device (schedule excluded).

Name	Audio	Preset	Record	Alarm Preview	Snapshot	Alarm Output
*Device Name_Camera01	ON	Null	Camera01	Null	Null	Null
Device Name_IP Cam	ON	OFF	Null	Null	Null	Null
Device Name_IP Cam	OFF	OFF	Null	Null	Null	Null

Select beside the title (like record) to enable record linkage of all devices (schedule excluded). Select "Link to itself (On)" to quickly select the camera itself as the record camera.



The alarm linkage settings of preset, record, alarm preview, snapshot, alarm output and TV Wall are the same with each other. Here take record linkage for example to introduce the setting steps.



Check the selectable channel and click to select the channel; check the selected channel and click to remove this channel;

click to select all channels; click to remove all selected channel.

After the channels are selected, check "On" and then click "OK" to save the settings.

Note: For TV wall alarm linkage settings, multiply TV wall pop-up windows can be linked to one channel.

Before checking voice broadcast, please upload the voice first (See [Audio Uploading Settings](#) for details).

Before checking Email, please set the sender's email address and the recipient address first (See [Email Settings](#) for details).

Before checking SOP, please set the SOP first (See [SOP Settings](#) for details)

③ Set alarm schedule. Select the schedule of the desired device. 7*24 or 5*24 is the default schedule. Other schedules need to be set in

advance. Click the “Schedule Setting” tab to set (See Schedule Recording→To set schedule for details).

Note:


1. For the alarm linkage items related to face recognition, you can set them separately, including face comparison alarm linkage, stranger alarm linkage, block list alarm linkage.
2. For the combined alarm of DVR/NVR, you can configure the alarm linkage items in the platform. If the combined alarm is set after the NVR/DVR is added to the platform, the platform cannot automatically receive the combined alarm data. Please reboot or reconnect your NVR/DVR and then the platform will display this device under the alarm type of “Encoding device-combined alarm”.

11.3 SOP Settings

Click the “SOP Setting” tab in the alarm center interface to go to the following interface as shown below.

1. Click “+” to add a SOP name.
2. Click “Create” to create a SOP action.
3. In the alarm linkage settings interface, select the alarm event and enable SOP of the relevant device.
4. Click  to extend the alarm list.
5. Click  to handle the alarm. Select the SOP action and then click “Save Process”. After that, choose disposition and enter remark as needed.

The disposition includes: False alarm, true alarm, customer test, technical event, service test.



After the alarm is processed, the alarm handling status and disposition will be shown as below.

Alarm Time	Alarm Source	Alarm Type	Record & Playback	Device Playback	Storage Snapshot	Device Capture	Alarm Processing	Handling Status	Disposition	Remark
2023-10-18 19:26:13	Device Name_Camera01	Monitoring Point-Face Detection	⊖	⊖	📷	📷	📝			
2023-10-18 19:26:08	Device Name_Camera01	Monitoring Point-Motion Detection	⊖	⊖	📷	📷	📝	Processed	False Alarm	
2023-10-18 19:26:03	Device Name_Camera01	Monitoring Point-Motion Detection	⊖	⊖	📷	📷	📝			

If “SOP Filter” is enabled, the alarm events of the channel set the SOP will be listed.


11.4 Alarm Task Settings

In this interface, you can set the leaving alarm task.


Leaving alarm: When someone leaves the predefined area and doesn't come back within the set time duration, the system will perform alarm linkages.

To set a leaving alarm task:

1. Enter the Alarm Task Setting interface.
2. Click [Add] to add the alarm task.
3. Set the task name, interval time, schedule and choose the camera.
4. Multiple cameras can be added to an alarm task.



5. Set the alarm linkage items. In the alarm linkage settings interface, select the alarm type as "Alarm task-Leaving Alarm". Then enable the desired alarm linkage (like "Alarm preview") and set the schedule.



6. Go to the Device Setting interface to enable Intrusion and set the detected area.


Note:

1. The selected camera must support and enable intrusion function, or leaving alarm will not take effect. If the camera supports vehicle/people classification, please check "Human" as the detection target.
2. After the leaving alarm task is set and intrusion is enabled for the camera, when someone enters the predefined area and stays there, this person will be judged as "On Duty" so that leaving alarm will not be triggered and the intrusion alarm will not be displayed on the alarm list; but when this person leaves and doesn't return within the set time duration (interval time) or no one appears in the set time duration, leaving alarm will be triggered.

11.5 Email Setting

Alarm information can be received by the specified Email address if the Email parameters have been set in advance.


Click Home→Alarm Center→Email Setting to go to the following interface. Add the sender and recipient's email information here.



In the sender's Email information area, fill out the corresponding information and then click "Apply" to save the settings.


Clicking on the [Add] button adds the recipient information.

After that, in the alarm linkage setting interface, you can trigger Email.




11.6 Alarm View

Having set the alarm preview linkage, the alarm view window will prompt when an alarm is triggered.



In the alarm preview interface, you can select multi-screen display mode by right clicking on the preview window as shown below.



Click on the bottom right corner to expand the alarm list as shown above. Hover the cursor on the top of the alarm list and then a bidirectional arrow will appear. Drag the alarm list up or down to extend or shrink the alarm list.

Click or to play the record or captured images.

Right clicking on an alarm item displays a menu. Click “Alarm Preview” to jump to the alarm preview interface.

Alarm Time	Alarm Source	Alarm Type	Record & Playback	Device Playback	Storage Snapshot	Device Capture	Alarm Processing	Handling Status	Disposition	Remark
2023-10-18 19:26:13	Device Name_Camera01	Monitoring Point-Face Detection								
2023-10-18 19:26:08	Device Name_Camera01	Monitoring Point-Motion Detection								
2023-10-18 19:26:03	Device Name_Camera01	Monitoring Point-Motion Detection								False Alarm

11.7 Alarm Log


Alarm logs can be searched and exported by going to Home→Alarm Center→Alarm Log interface.

No.	Alarm Time	Alarm Source	Alarm Type	Details	Record & Playback	Device Playback	Storage Snapshot	Device Capture	Alarm Processing
1	2023-10-18 20:28:33	Device Name_Camera01	Monitoring P...						
2	2023-10-18 20:28:28	Device Name_Camera01	Monitoring P...						
3	2023-10-18 20:28:24	Device Name_Camera01	Monitoring P...						
4	2023-10-18 20:28:24	Device Name_IPC	Monitoring P...						
5	2023-10-18 20:28:13	Device Name_Camera01	Monitoring P...						
6	2023-10-18 20:27:59	Device Name_Camera01	Monitoring P...						
7	2023-10-18 20:27:36	Device Name_Camera01	Monitoring P...						
8	2023-10-18 20:27:28	Device Name_Camera01	Monitoring P...						
9	2023-10-18 20:27:23	Device Name_Camera01	Monitoring P...						
10	2023-10-18 20:27:22	Device Name_Camera01	Monitoring P...						
11	2023-10-18 20:27:22	Device Name_Camera01	Monitoring P...						
12	2023-10-18 20:27:17	Device Name_Camera01	Monitoring P...						
13	2023-10-18 20:27:03	Device Name_Camera01	Monitoring P...						
14	2023-10-18 20:26:58	Device Name_IPC	Monitoring P...						
15	2023-10-18 20:26:51	Device Name_Camera01	Monitoring P...						
16	2023-10-18 20:26:37	Device Name_Camera01	Monitoring P...						
17	2023-10-18 20:26:31	Device Name_Camera01	Monitoring P...						

Click to play the record; click to open the snapshot search window as shown below.

11.8 Manual Alarm Out

Click “Manual Alarm Out” tab to go to the following interface.



Select the camera, set the alarm holding time and then click [Trigger] to manually trigger the alarm out of the camera; click [Clear] to manually turn off the alarm out of the camera.


12 E-Map

The e-map service is used to store the e-map information of the system. The client landing anywhere can share the same e-map.

12.1 E-Map Settings

12.1.1 Create E-Map


Go to Home→E-Map Setting interface. Click [Create Map] to create a map.




Enter E-map name, select parent e-map and map type. Then click [OK] to save the settings.

12.1.2 Add Hotspot

The hotspots include monitoring points and sensors. Drag a hotspot to the corresponding area on the map as shown below.






Put the cursor on the map name and then some icons will appear. Click  to add its sub map. Click  to modify the map name and change its parent map.




Click  to delete the added map.

Click  at the bottom of the interface and then right click on hotspot alarm item. Select "E-Map" to quickly skip to E-map monitoring interface.

Alarm Time	Alarm Source	Alarm Type	Record & Playback	Device Playback	Storage Snapshot	Device Capture	Alarm Processing
2023-10-18 19:39:00	Device Name_Camera01	Monitoring Point-Motion Detection					
2023-10-18 19:38:48	Device Name_Camera01	Monitoring Point-Motion Detection					
2023-10-18 19:38:09	Device Name_Camera01	Monitoring Point-Motion Detection					

12.2 E-Map Monitoring

Go to Home→E-Map Monitoring interface. Select a window on the right and then double click the monitoring point to view the real-time image.




Switch to Alarm E-Map: if “Yes” is selected, the system will automatically switch to the E-map on which the alarm occurs.

Auto Alarm View: if you select “Yes”, the monitoring video will automatically pop up on the right window when an alarm is triggered.

Put the cursor on the preview window (right panel) and then a toolbar will display. Clicking on  closes the preview. Click “Close All Stream” to stop all previews. The preview window will be overlaid on the map by clicking “Overlap”.


In addition, click [Filter Alarm Type] to filter the alarm type.

If multiple cameras need to play, you can drag the window on the right panel to the right. Then an independent monitoring interface will display. You can choose the screen display mode as needed.



13 TV Wall

Click  at the bottom right corner and then select “TV Wall Guide” to quickly set the TV Wall as shown below.




Please follow the guide in sequence to quickly set the TV Wall.

13.1 Add Device

13.1.1 Add Decoder

Decoder is used to decode the video signal transmitted by the transfer server. The decoding output is a standard video signal. The decoder is necessary for decoding videos on the TV wall.

Go to Home→Add, Edit or Delete Device→Decoder interface.




The steps for adding decoders are the same as the setup for adding encoding devices (see Add Encoding Device for details).

13.1.2 Create and Connect Decoder

The decoder which needs to be connected to the platform must be the master decoder and in platform mode. Login the web client of the decoder as shown below.

Go to Basic Settings→ System Settings to check the user permission and running mode of the decoder and make sure its user permission is master and its running mode is platform. Then apply the settings and restart the decoder.




The decoder will not be online until it is bound to a TV wall. Please create a TV wall first and then bind the decoder to the TV wall.

13.2 TV Wall Management

◆ Create TV Wall

Go to Home→TV Wall → TV Wall View. Select a TV wall server and then click  to create a TV wall.




Select the TV wall server and then set the TV wall name, display matrix and TV wall number.

Note: The TV wall number cannot be used repeatedly.

Click [Draw] to draw the TV wall layout manually.

After that, click [Next] to bind decoders.



On the left list, click  to bind the decoder. If there are no decoder to bind, you can click  to quickly jump to the decoder adding interface and then add the decoder as needed. After you clicking , it needs several seconds to connect the decoder. After the decoder is connected, the output will be listed under the decoder name.

If you want to unbind the decoder, click  behind the decoder name to unbind it.

Drag the output to the window to bind the output and the window. After that, click [Finish] to save the setting.

To change the output binding, select the TV wall and click , select  to modify. Click  to delete the TV wall.

13.3 TV Wall System Settings


13.3.1 Channel Number Settings

Channel number configuration: set the channel number and make the channel convenient to be controlled by the network keyboard controller. Users can export these channel number in this interface.



No.	Name	Channel Number
1	default area-->Device Name_IPC	1
2	default area-->Device Name_IPC	2
3	default area-->Device Name_IP Camera01	3
4	default area-->Device Name_IP Camera03	4
5	default area-->Device Name_Camera01	5
6	default area-->Device Name_IPC	6
7	default area-->Device Name_IPC1	7

13.3.2 Decoder Setting



Display red box: when the decoding channel triggers alarm, a red box will show on the TV Wall.

Display ID: the channel ID will be shown on the channel decoded by the decoder


13.3.3 TV Wall Alarm Linkage Settings

Click “Alarm setting on TV Wall” and then the alarm closing time can be set. If “Automatically closing alarm on Wall” is selected, you can set the time that TV wall alarm automatically turns off. The alarm preview window will automatically turn off the alarm linkage video according to the set time until next alarm is triggered. If not selected, you need to close the alarm preview window manually.

13.4 Video Preview

◆ Create a plan

Click  beside the TV wall name or click [Create Plan] to create a new plan for the created TV wall.




Double click the plan name to show the plan.


Drag the monitoring points to the corresponding window respectively to decode image. Then click  to save the plan.

◆ Configure Plan


Double click the set plan to display on the left window as shown below. Drag the monitoring point to the window to play.



◆ Toolbar Menu




1. Screen mode: 1\4\9\16\25\36 screen mode is optional.
2. Open Window: Click this icon and then drag on a window to open a window on it. The window can be dragged to anywhere on the big window. Click the opened window and then drag the blue side of the window to zoom in/out it. Click this icon again to stop opening other windows.




3. Show/hide ID: show or hide all ID number (including all channel numbers of the multi-screen display window).
 4. Show/hide window ID: show or hide the ID number of all windows (Note that the channel numbers of the multi-screen display window are not displayed).
 5. Click [Save] to save the current plan.
- Select a window assigned a monitoring point and then press the right mouse and drag to another window to copy monitoring point to it.


◆ Right-click Menu



1. Screen display mode:1\4\9\16\25\36 screen mode is optional.
2. Preview: click it to view the video.



3. Save as Alarm Window: click it to save the current window as an alarm window. The alarm linkage image will be displayed in this window. Go to Home→ Alarm Center→Alarm Setting interface. Select TV wall linkage item to set alarm linkage.



4. Set as Playback Window: when decoding images, click this menu to play the records of the current channel (the record source is the current record source).

5. PTZ Control: click this menu to prompt a PTZ control panel of the current decoding window. Direction control, zooming and focusing, Iris control, speed, preset, track and cruise calling can be operated through this control panel.


6. Stop Decoding: click it to stop decoding the current image.

7. Play audio: click it to play live audio. Click “Stop audio” to stop playing.


◆ Auto-Switch Group

1. Create Auto-Switch Group


① Click Auto-Switch Group under the screen and then click  to create auto-switch group.



② Select "Auto-Switch Window" to select the window group.




③ Click [Next] to select the auto-switch channel group.



④ Enter auto-switch name and dwell time.

2. Execute auto-switch




Click  to execute auto-switch. The specified channel images will be played in the specified windows in sequence.

Click  to stop playing the current auto-switch group.

3. Modify or delete auto-switch

Right click on the auto-switch group name and select Modify or Delete to modify or delete the auto-switch.


Or click  and then select the corresponding icon to modify or delete the auto-switch.



◆ Auto-switch plan

1. Create auto-switch plan

Click  behind the TV wall plan name and then click  to set the auto-switch. Click "Join in" to select the plan. Then set dwell time and click [OK].



2. Start/stop auto-switch



Click  behind the TV wall name to start auto-switch plan. Click  to stop the auto-switch.

3. Modify auto-switch plan

Click  again to modify the auto-switch plan.

Note: If the current auto-switch plan needs to modify, please stop it first.


13.4.1 Decoder Input

Go to Home→TV Wall Management→Decoding on TV Wall→Decoder Input. Drag an input to a window to execute decoding.

13.4.2 Playback

◆ Playback on TV Wall

Click “Record”, select playback source and time, check the alarm events and then drag the cameras (or channels) to a window to search and play the records.



◆ Playing control




During playback, the record can be controlled by the above buttons.

Note: The frame rate per second will be the same as the set frame rate of the device (Home→Device Setting→Stream Setting→Frame

Rate).

◆ **Right-click menu**




1. Screen Display Mode: 1\4\9\16\25\36 screen mode is optional
2. Save as an alarm window: click it to set the current window as an alarm window. The alarm linkage image will play in this window. Please go to Alarm Center→Alarm Setting interface. Select the alarm type, link the TV wall and set the schedule first.
3. Save as preview window: the current camera or the historical camera is optional. If the current camera is selected, the window will display the live video of the current camera in the record page. If the historical camera is selected, the window will display the live video of the camera decoded in this window last time.
4. Playback stream type: main stream or sub stream is selectable.
5. Stop decoding

The following picture is an example of TV Wall.




13.5 TV Wall Task Setting


Go to Home→TV Wall Management→Task Setting. Select the TV wall you want to set tasks. Then click “Create Task”.
Select plan name, enter task name, set run time and enable plan task.



Click "Start Task" to start the task. Click "Stop Task" to stop this task.




Modify or delete task



Click  or  to modify or delete the task.


Check the task under the TV wall and then click [Delete] to delete the task as shown below.



13.6 TV Wall Backup

When importing the former system configuration files to the new version, the TV wall configuration file will not be imported together. So you need to import the TV wall configuration file separately.

Click [Backup TV Wall] in the last version to back up the TV wall configuration files. Then click [Restore TV wall] in the new version to restore it.




14 Target Counting

14.1 Task Management


1. Enable “Target Counting” function of the IPC.

Note: the added camera must enable target counting function.

IPC with Target Counting function




2. Go to Home→Target Counting interface. Clicking on  enters the following interface. Double click the camera with the target counting function and then select “ON”. After that, click [Apply] to save the settings.



14.2 Real-time Statistics

Go to Home→Target Counting→Real-time Statistics. Double click the camera with the target counting function to view the live image. The camera will automatically count the number of people/motor vehicle/non-motor vehicle crossing the predefined line and the system will automatically analyze the traffic flow trends.

Before view the statistics, please go to Home→Resource Management→Device Setting→Target Counting interface to set the alert line, entrance/exit, detection target, etc.



Please select the type as needed to view the flow trend. Click Refresh to refresh the current statistics. Set the auto refresh interval: The system will automatically refresh the statistics at regular intervals.

In the above interface, you can view the statistics of people/vehicles entering or exiting. Scroll down to view the traffic flow statistics via pie charts and tables.



14.3 Heat Map

Go to Home→Target Counting→Heat Map interface.

Please create a map first.

Drag the camera with the target counting function to the specified area.


Put the cursor on the camera icon and then you will see the detailed flow statistics.



The deeper the red color is, the more targets (human/vehicle) gather there.

14.4 Historical Statistics

Go to Home → Target Counting → Historical Statistics. In this interface, the statistic results in a long period of time can be searched which can be shown in the table or curve chart. Additionally, the statistics of different targets can be viewed here.




14.5 Flow Control


Flow Control: Control the people/vehicles entering or exiting in a specified area to avoid overcrowding. When the people/vehicles stay in the specified area exceeds the threshold, the alarm will be triggered and no entry icon will display.

Click Home → Target Counting → Flow Control to enter the following interface.

Click **+** to add a task. Multiple tasks can be added as needed.



Then the available number and inside number can be viewed as below.



Click  to view the quantities of the people/vehicles entry and exiting.

Click  to enter the flow control preview interface.



In the above interface, you can switch the camera and view the image. When the people/vehicles inside exceed the threshold, the icon will turn red.

Click on  exits the current page.

15 Visitor Management

The system provides an entire process for visitor management. You can manage visitors through access control devices and this system.

15.1 Add Access Control Devices

You can add a face recognition & access control terminal to manage visitors.

Click Home→Resource Management→Add, Edit or Delete Device→Encoding Device to add face recognition & access control devices.


Note: Access control devices includes face recognition & access control terminal, face recognition IPC, face recognition NVR, but the face recognition IPC and NVR only can record the access records of the visitors. Please contact our technical supports to get the detailed models.

15.2 Apply for a Visit

There are two ways to apply for a visit.

1. Go to Visitor List→ Visitor Registration interface. Click “Visitor Registration” to add a visitor.

Fill out the information of the visitor and then select the visatee as needed.




The screenshot displays the 'Visitor Registration' interface. On the left, there is a 'Visitor List' sidebar with a 'Create' button and a search bar. The main area is titled 'Add Target' and contains two tabs: 'Basic' (selected) and 'Access Control'. The 'Basic' tab includes the following fields:

- Visitor information:
 - No. (text input)
 - * Name (text input)
 - Gender: Male Female
 - Telephone (text input)
 - Address (text input)
 - Remark (text area)
- Certificate:
 - ID Type: ID Card (dropdown menu)
 - * ID NO (text input)
 - Birth Date: 2023-12-25 (calendar icon)


On the right side of the form, there is an 'Upload' button and a note: 'Image size: less than 200KB is recomn'. At the bottom right, there are 'Next', 'OK', and 'Cancel' buttons. A red circle highlights the 'Visitor Registration' button in the top navigation bar, with a red arrow pointing to the 'Add Target' form.

Select the access point.



Visitor Permission Group Settings:


Click “Set the visitor permission group” to skip to the permission management interface. Click “Visitor Permission Group” to set the permission of visitors as shown below.




Click [Add] to add a visitor permission group. Set the permission group name and add the access point as needed. You can also modify the permission for the added visitor permission group here.

2. Add a visitor via the shortcut key


- (1) Add a visitor from the alarm pop-up window of face comparison



(2) Add a visitor from the snapshot from smart snapshot retrieval interface



(3) Add a visitor from the real-time smart snapshot interface




Note: if the operator has no permission of visitor adding, he/she cannot add visitors.

15.3 Search and Export Visitor Record


Set the start and end time and then click [Search] to search the visitor record.

You can also enter the key words and click  to search the visitor record.

Click [Export] to export the visitor record to an Excel file. Note that only the super administrator supports visitor record export.



After the access control device is linked to the visitor, the access control device will report the matched information to the platform when the visitor comes.





15.4 Exception Handling


15.4.1 Extending Visit Time or Modify Access Point

There are two ways to handle the exception.

1. Go to Visitor Management → Visitor Registration interface as shown below.



2. Go to Visitor Management → Record Search



For valid record, you can edit the visit time period and access point.

Please set the expired time or extend the visit time period as needed.

Access Control Permission Group: if the access point or visitor permission group is unbound, the access permission of the corresponding visitors under this access point or visitor permission group will be ineffective.

15.4.2 Not Visiting/Leaving Beyond the Given Time

When someone's visiting is about to exceed the given time or the pre-registered visitor doesn't come within the given time, a prompt

window will appear to remind the operator to extend the visit time or take other actions.

If this prompt window is not handled, the visitor will be marked as "Timeout".


Clicking on the [Timeout] button appears the relevant records

For the timeout record, you can modify the access permission and manually give the permission and extend the expired time.

Click "Finish" to end this record process immediately.

16 Parking Lot Management

Click  at the right bottom corner of the home page. Select “Parking Guide” to quickly view the setting steps of the parking lot management.



In the parking guide interface, click the corresponding menus in sequence to quickly set the parking lot.

16.1 Add Devices

● Add LPR Camera

Before using parking lot system, please add LPR cameras first. The LPR camera is use to capture the license plate of the vehicles entering or exiting the parking lot.


There are two ways to add LPR camera.

1. Click Home→Resource Management→Add, Edit or Delete Device→Encoding Device to enter the encoding device adding interface. Click [Add] to add your LPR camera.
2. Add the LPR camera to your NVR with license plate recognition function and then add this NVR to the platform.

● Add LED Display Screen

Before using parking lot system, please add the LED Display Screen which is used to display the information of the vehicles entering or exiting the parking lot.

Click Home→Resource Management→Add, Edit or Delete Device→LED Display Device to go to the LED display device adding interface.



Port: the default port is 5000.

Type: please select IP screen.

IP address: enter the IP address of the IP screen.

16.2 System Settings

16.2.1 Parking Lot Settings

Go to Parking Lot Management → System Settings → Parking Lot Configuration as shown below.

The screenshot shows the 'Parking Lot Configuration' page. The left sidebar has 'Parking Lot Configuration', 'Vehicle Group Management', and 'Block List Management'. The main area is titled 'Basic Configuration' and includes:

- Basic Configuration:** Parking Lot (text input), Allow temporary vehicle access even if the parking space is full (checkbox), Total Parking Space (100), Remaining Parking Space (100), Number of the current vehicles (0), Number of overflow vehicles (0), Barrier Gate Opening Duration(s) (15), Repeated license plate waiting time (5).
- Temporary vehicle timeout configuration:** Enable overtime parking of temporary vehicles (toggle), Temporary vehicle timeout threshold (hours) (720), Daily alarm time (15:00).
- license plate configuration:** Special license plate (WJ,police,civil aviation).
- Entrance/Exit Setting:** Entrance Name (Gate), Lane Management (checkbox).

Lane Name	Lane Type	Temporary car opening method	Fixed Car Opening Method	Linked ANPR Camera	Linked LED Screen
Entrance Lane	Entrance	Release	Automatic Release		
Exit Lane	Exit	Release	Automatic Release		

An 'Apply' button is at the bottom right.

- **Add or Delete Parking Lot**

Click + to add a parking lot as shown below.

The screenshot shows the 'Parking Lot' section with a '+' icon circled in red. A 'New parking lot' dialog box is open, containing a 'Parking Lot' text input field and 'OK' and 'Cancel' buttons.

Select the parking lot and click  to delete it. Note that there must be no entrance or exit or vehicle group under the parking lot, or it cannot be deleted.

- **Basic Configuration**

Select the parking lot and then set the relevant parameters for it. You can modify the parking lot name, set whether to allow temporary vehicle access even if the parking space is full, total parking space, number of the current vehicles (in order to ensure the accuracy counting of remaining parking space, please make sure that no vehicle entering or exiting), remaining parking space, number of overflow vehicles, barrier gate opening duration and repeated license plate waiting time. After that, click [Apply] to save the settings.

Total Parking Space: the set total parking space

Number of the current vehicles: the number of vehicles staying in the parking lot

Remaining parking space: Total parking space minus the number of the current vehicles (if the number of the current vehicles is more than or equal to the total parking space, the remaining parking space will be "0").

Number of overflow vehicles: the number of the current vehicles minus total parking space (if the number of the current vehicles is less than the total parking space, the remaining parking space will be "0").

Repeated license plate waiting time: the same license plate will be identified once within the set waiting time

- **Temporary Vehicle Timeout Settings**

Overtime Parking of Temporary Vehicles: if enabled, timeout threshold and daily alarm email sending time should be set. Once the temporary vehicles that stay in the parking lot exceed the set timeout threshold, an email will be sent according to the set time.

- **Entrance and Exit Settings**

Click [Add] next to “Entrance/Exit Setting” to create an entrance/exit. You can directly modify the entrance name and click [Apply] to save the setting.

For the added entrance/exit, click  to delete it. Before deletion, please ensure that there is no lane information under it, or it cannot be deleted.

- **License Plate Configuration**


You can enter the special characters. When detecting the license plate including the set special characters, the system will automatically release.

- **Lane Management**

Click [Lane Management] next to the entrance name. This will bring a lane setting window. Click  to add a new lane. Set the lane name, lane type and temporary car release way (manual/auto release). After that, click [Apply] to save the settings.


- **Binding LPR Camera**

In the lane management window, click [Setup] of the linked LPR camera line to bind the LPR camera as shown below. Multiple cameras can be bound to one lane.




- **Binding LED Screen**

In the lane management window, click [Setup] of the linked LED screen line to bind the LED screen as shown below. One screen can be bound to one lane only.




- **Binding RS485 Screen**

In the lane management interface, you can also bind RS485 screen. Enable RS485 screen, select the screen type and then click [Apply]. Before binding RS485 screen, please ensure that the license plate capture camera has been connected to the screen via RS485 interface.



- **Binding Vehicle Group**


In the lane management window, click “More” to bind vehicle group. Select the vehicle group as needed. Then click [Apply] to save the setting. All vehicles in the vehicle group bound to the lane will be allowed to enter/exit in the parking lot.




Note: A parking lot can add multiple entrances and exits; an entrance/exit can add multiple lanes; a lane can bind multiple license plate capture camera; but one license plate capture camera only can be bound to one lane of the entrance/exit in the parking lot. The name of the parking lot cannot be repeated; the names of entrances/exits in the same parking lot cannot be the same; the names of the lanes in the same entrances/exits cannot be the same.

- **Other Settings**

In the system settings interface, click  at the top right corner to set the LED display and alarm linkage switch.




Alarm linkage: please enable “Block List”, “Allow List”, “Temporary Car” as needed. If these alarm linkages are enabled, click  at the bottom right corner to view the corresponding alarm information.




Additionally, only when the above-mentioned alarm linkages are enabled, can the corresponding alarm linkage be set successfully in the alarm center. Go to Home→Alarm Center→Alarm Setting interface, set the alarm type (Parking-Parking, Blacklisted vehicles; Parking-Parking Allow list vehicle; Parking-Parking, Temporary vehicle), select the bound license plate recognition camera (or the bound LPR camera), enable the desired linkage items and set the schedule.

After that, when detecting the corresponding vehicles, the system will trigger alarms accordingly.



16.2.2 Vehicle Group Management


Go to Parking Lot Management→System Settings→Vehicle Group Management interface as shown below.




● Add, Modify or Delete Vehicle Group

Add Vehicle Group:

Move the cursor onto the parking lot name and then “+” will be shown. Click this icon to add a vehicle group. Enter the vehicle group name and then click “More” to set more parameters.



Click  to set the passable area of the vehicle group and admission schedule.




Check “Separate allocation of parking spaces” to separately set total parking spaces and the number of the current vehicles of the vehicle group”.

Modify or Delete Vehicle Group:


Move the cursor onto the vehicle group name and then  will be shown. Click this icon to delete. If there are vehicles added in the vehicle group, it cannot be deleted. You must delete all vehicle information first and then this vehicle group can be deleted.

Move the cursor onto the vehicle group and then  will be shown. Click it to modify the vehicle group name, passable area and admission schedule. After that, click “OK” to save the settings.



Vehicle Information Settings

Add Vehicle Information: Select the vehicle group, click [Add] to add a new vehicle. Fill in the relevant vehicle information. The number plate must be entered.



Delete Vehicle Information:

Select the vehicle information and then click [Delete] to delete the vehicle information.

Note: If the vehicle information you want to delete is bound to other vehicle groups, it will be deleted too in other vehicle groups.

Bulk Binding: in the vehicle group management interface, select the vehicle group and click [Bulk Binding] to bind other vehicles to this vehicle group.

Note: one license plate only can be bound to a vehicle group of other parking lots. It cannot be bound to other vehicle groups of the same parking lot.

File Import: Click[Download Template] to export a .csv or .xlsx file. Then open the template, edit all vehicle information and then save it.

Click [File Import] and then select the edited file to import all vehicle information.

.csv template file includes three attributes, including plate number, owner’s name, owner’s phone.

	A	B	C	D
1	(B1) Number	(B2) Owner	(B3) Owner's	Phone
2	A123456	Simon	1111111111	
3				
4				

.xlsx file includes many attributes, including plate number (compulsory), owner, owner, phone, vehicle color, vehicle type and so on.

	A	B	C	D	E	F	G	H
1	#####							
2	Number plate	Owner's Name	Owner's Phone	Description	Vehicle Type	Vehicle Color	Start Time	End Time
3	A123456	Simon	1111111111	Discription	Small Car	Blue	2022/01/13	2022/01/13
4								
5								


Unbind Vehicle: Select the vehicle you want to unbind and then click [Unbind selected]. In the pop-up window, click [OK]. This vehicle will be removed from the current vehicle group. The vehicle information will not be deleted and the binding relationship between the vehicle and other vehicle groups will not be changed. This vehicle also can be bound to the other vehicle group of this parking lot. You can also click Unbind to unbind.

Modify Vehicle Information: in the vehicle group management interface, select a vehicle and then click to change this vehicle information.

Vehicle Search: in the search bar, enter the key words to search the vehicle information.

16.2.3 Block List Management

Go to Parking Lot Management → System Settings → Block List Management interface as shown below.



Block list is created by default. Click [Add] to add the vehicle information. The plate number must be entered. The vehicles added to the block list cannot be added to any other vehicle groups.

Select the vehicles and then click [Delete] to delete the vehicles from the block list. Import the vehicles to the block list is the same as vehicle import to other vehicle groups.


Click  to modify the vehicle information in the block list. Click [OK] to save the settings.

16.3 Vehicle Monitoring

Click Parking Lot Management → Vehicle Monitoring. Then you can view the real-time lane monitoring video, vehicle passing information, remaining parking space and so on.

16.3.1 Real-time Vehicle Preview

Drag the camera on the left panel to the preview window to view the real time video. 1/2/4/9/16 screen display mode and stream can be selected. Click  to close all previews.



16.3.2 Pass Records

Under the preview window, you can view the real-time vehicle passing records. If “Only display the current preview window records” is checked, the system will only display the vehicle information identified by the camera that is playing in the preview window. If disabled, the vehicle information identified by all cameras under all parking lots will be displayed. You can also filter the passing record by selecting “Auto Release”, “Manual Release” or “Not Released”.

When the scrollbar on the right of the passing record area is in the top or bottom, the passing record may not refresh; when the scrollbar in the middle, it will stop refreshing and the current passing record page will not change.

16.3.3 Pass Information

On the right panel of the vehicle monitoring interface, it shows vehicle passing information. In the current area, you can view the vehicle image, license plate, lane type, vehicle type, term of validity, enter information and the vehicle status. You can also modify the information of vehicles unreleased (or manually released), including license plate, vehicle type and so on.

Select a preview window and then the passing record area will refresh the vehicle information identified by the camera; Select a passing record, vehicle pass information area will display the selected vehicle information and the passing record will not refresh. Re-select the preview window to continue refreshing.

On the top right of the vehicle monitoring, it is total parking space and remaining parking space display area. Click  to edit the total parking space and remaining parking space. Please make sure there is no vehicle entering or exiting before modification in order to guarantee the accuracy counting of the remaining parking space.

16.4 Integrated Search

16.4.1 Search Pass Information

In this interface, the information of the vehicles entering and exiting the parking lot can be searched.


Set the filtering condition, such as the start and end time, license plate, vehicle type and lane. Click [Search] to search the records.

Click a passing record and then the corresponding license plate image will be displayed on the right. You can zoom in and download it.

At present, up to 3,000,000 passing records can be stored and 120,000 vehicle passing images can be matched to these passing records.

To modify passing record: select a passing record, click [Modify], select the vehicle type and click [OK].

To export the parsing record, search the desired passing record and then click [export] to export the records to the specified file named after “Integrated Search + data” (eg. Integrated Search_20220112_11233555). The export file is .xls file.




16.4.2 Search Overdue Parking

In this interface, you can check the information of the vehicles which stay in the parking lot longer than the predefined parking duration. Before searching, please make sure you have enabled overtime parking of temporary vehicles in the parking lot configuration interface. (Click Home→Parking Lot Management→System Settings→Parking Lot Configuration)

16.4.3 Search Vehicles in the Parking Lot


Set the filtering condition (start time, end time, plate number, vehicle type, parking type or parking area), click [Search] to search vehicles in the parking lot. Click [Export] to export the searched vehicle information in the parking lot.



If the searched vehicle has actually been driven away, you can click  to correct. Then the vehicle will not be searched in this interface.

16.5 Report Statistics

Go to Parking Lot Management→Report Statistics interface. In this interface, vehicle flow statistics of all parking lots can be searched and viewed via line chart, bar graph and pie chart.




On the left panel, select the parking lot and entrances/exits you want to view the statistical information. Then select the report type and

data. Click  to select the desired date; click  to select the date range. After that, click [search] to display the statistical information.

The default granularity is “Entrance”. You also can select “Parking Lot” and click [Search] to refresh the vehicle flow data. The report type, time and granularity will be shown on the top of statistical information. The total number of vehicles entering or leaving can be viewed too.

Click  to view the data statistics in the line chart; click  to view the statistics in the bar graph. You can view the entrance or exit information as needed. Put the cursor on the statistic chart/graph to view the detailed information.



Export: You can choose to export Excel or image as needed. Click [Export Excel], select the path and then click “Save” to export the files(.xls). The file name format is “Report Statistics_ Date”.


Click [Export Picture] to export pictures (.png format).

17 Body Temperature Measurement

17.1 Add Temperature Reading Devices

This platform supports thermal network camera and temperature measurement panel access.


1. Click Home→Resource Management→Add, Edit or Delete Device→Encoding Device to go to the encoding device interface. Click [Add] to add the temperature reading devices.
2. Click Home→Resource Management→Device Setting to go to the device setting interface. Select the temperature reading device and then click the “Thermal imaging settings” tab to enable temperature measurement function.
3. Set the temperature unit, high temperature threshold and low temperature threshold (different devices may have different settings).
4. Click [Apply] to save the settings.



17.2 Temperature Screening

17.2.1 Configuration

1. Click Home→Temperature Measurement→Live Preview→ to go to the following interface.
2. Set the temperature measurement parameters as needed.



Abnormal temperature threshold: please set the value according to the actual condition. When the temperature detected is over than the set value, alarms will be triggered.

Record validity: Set how long the platform will keep the temperature records. If it is enabled, the temperature records will be cleared beyond the set days.

Pop-up automatically: if enabled, the abnormal temperature alarm processing box will pop up automatically. Additionally, you can enable “Pop up non-mask alarm box” as needed.

Data Display: you can choose “Hide normal data”. That is to say, if the temperature of the person scanned is normal and the mask is detected, these data will not be displayed on the client.

Data Reset Settings:


- a. Reset time and type: please reset time of the temperature data as needed. These data can be reset every day, every week or every month.
- b. You can reset the statistics by clicking [Reset].

Data sources of Temperature Reading Table: including comparison data and detection data. If comparison data is selected, the platform will receive the temperature reading result and face comparison result; if detection data is selected, the platform will receive the temperature reading result and face detection result, but it is not sure whether the person is matched with that of the face database

Voice Prompt: Please set the over temp voice prompt and non-mask voice prompt as needed. When no mask or elevated temperature is detected, the set voice prompt will be heard.

17.2.2 Live Preview

Drag the thermal cameras/temperature measurement and face recognition terminals to the preview window. In this interface, you can view various statistical information, such as total pass-by(today/total), over-temperature(today/total), mask off (today/total), etc.



Putting the cursor on the snapshot picture appears a “+” icon. Click this icon to add this picture to the group of the face database.

The thermal image and visible light image will be displayed simultaneously if the thermal camera is dragged to the preview area. Right click on the thermal camera window and then select the fourth stream to view the thermal image.

➤ **Alarm Handling**

Click the captured image to pop up an alarm handling box as shown below. You can edit the personal information, including name, phone number, ID number, address, whether to go to the infected area, etc.

Click “+” on the top right corner of the snapshot image to add it to the group of the face database.

Pop up automatically: if enabled, the alarm handling box will automatically pop up on detecting an abnormal event (over temp/mask off).

➤ Full Screen Display

In the temperature measurement interface, click  on the top right corner to enter temperature warning system interface.

Click  to exit the full screen mode.

17.2.3 Record Search

Select the camera and then set the filter condition (like the start and end time, temperature range, keywords, etc.) to search the records.

No.	Suspected fever	Snapshot Camera	Time	Target Picture	Original Picture	Temperature	Mask Status	Status	Alarm Handling	Record Playback	Processing Status
1	No	IPC	2023-12-25 11:15:30			36.7°C	Mask Off	Unprocessed			

In the above interface, you can view the target picture and the original picture, body temperature, mask status, alarm handling status, etc.

17.2.4 Statistics

In the statistics interface, you can view the total pass-through counts, abnormal temperature counts and mask off counts.



: Click it to switch between date and date range.

Choose the camera and then set the start time and end time. Click “Search” to view the statistics.

You can view the statistics via a line chart or bar graph. The statistical data can be exported by clicking “Export”.


18 Industrial Temperature Measurement

18.1 Thermal Network Camera Settings

Click Home→Resource Management→Add, Edit or Delete Device→Encoding Device to go to the encoding device interface. Click [Add] to add the security thermal network cameras.

18.1.1 Temperature Measurement Settings

After adding the security thermal network camera, click Resource Management→Device Setting→Temperature Measurement Configuration to go to set the temperature measurement parameters.




Color Type: White/Black/Rainbow coding/Red

Restore: Click it to restore the set image to the previous image.

18.1.2 Temperature Alarm Settings

In the device setting interface, select the security thermal network camera and then click the temperature alarm tab as shown below.




Enable temperature alarm.

Set the rules. Up to 10 rules can be set.

Double click rule name, type, emissivity, distance and reflective temperature of each rule to modify them.

The rule type includes point, line and area.

Edit: set the alarm rule.



After the above alarm rules is set and temperature alarm is enabled, set the alarm linkage items of monitoring point-temperature alarm in the alarm linkage interface. When the detected temperature exceeds the set threshold, the related alarms will be triggered.

Start Draw: select the type and then draw on the image.


Clear: clear the drawn point/line/area.

Schedule: Set the schedule of temperature alarm.

Alarm Setting: Set the alarm of the IPC.

18.1.3 Fire Detection Settings

In the device setting interface, select the security thermal network camera and then click the fire detection tab as shown below.



Schedule: set the schedule of fire detection, 7*24 by default.

Alarm Setting: set the alarm of IPC.

Apply: Click it to save the settings.


Enable: Check it to enable the fire detection function.

18.1.4 Alarm Linkage Settings

Click Alarm Center→Alarm Linkage Settings→Monitoring Point-Fire detection alarm

Enable the alarm linkage items, like record, snapshot, alarm output, etc.


When the detected temperature exceeds the set threshold, alarms will be triggered.



18.2 Temperature Measurement


18.2.1 Video Preview

Go to the video preview interface and then drag the thermal camera to the window to play. The default video stream is the fourth stream (thermal imaging stream). You can switch the stream under the preview window. The temperature measurement rule and the current temperature will be displayed in the image. When the temperature alarm is triggered, they will turn red.




18.2.2 Data Analysis

Select the data analysis tab to enter the following interface. Select the temperature measurement rule (multiple rules can be selected) and click [Apply] to view the real-time temperature reading results and image.



Temperature measurement settings: Click  to open the temperature measurement setting window. You can choose whether to display detection rules and real-time temperature, set sensitivity and temperature rise alarm.




You can set the alarm linkage items of temperature rise alarm. When the rise of the temperature exceeds the set value, the relevant alarms will be triggered. Go to Alarm Center→Alarm Linkage Settings interface and select “Monitoring Point—Abnormal temperature rise” to set the alarm linkage items.

Note: At present, the system will detect the temperature every 10s. If the temperature goes up 0.1°C every one second, the temperature will rise up 0.5°C after 5 seconds, but alarms will not be triggered immediately. Alarms will be triggered when the temperature rises up 0.5°C or higher after 10 seconds.

Different colors stands for different temperature measurement rules. You can view the temperature reading results.

Statistical type: Maximum/average/Minimum temperature.

Show dots: if enabled, the statistical temperature plot will show the dots as shown below. Put the cursor on the dot and then the detailed data will be displayed.




: Click it to export the temperature measurement data to the specified file.

Refresh Rules: Click it to refresh the monitoring points and then select the desired rules

Apply: After you select rules, click it to view the line chart.

Real-time Preview: click on the right to extend the video preview window. Select a rule on the left monitoring point panel, this rule will be highlighted. Click any point in the preview window to view the real-time temperature.



18.2.3 Record Search

Click Industrial Temperature Measurement → Search to go to the following interface. Select one or more rules, set the start and end time and click [Search] to view the temperature data.

Video Preview Data Analysis Search

Monitoring Point

Search

default area

Time

2023-12-25 00:00:00 - 2023-12-25 23:59:59

Search

Export

No.	Time	Monitoring Point Name	Minimum Temperature	Average Temperature	Maximum Temperature	Area
1	2023-12-25 17:14:37	_thermal	26.25°C	26.95°C	27.55°C	Line 1
2	2023-12-25 17:14:37	_thermal	25.45°C	26.55°C	27.35°C	Area 8
3	2023-12-25 17:14:27	_thermal	26.85°C	26.75°C	26.85°C	Point
4	2023-12-25 17:14:27	_thermal	26.25°C	26.75°C	27.35°C	Area 7
5	2023-12-25 17:13:47	_thermal	27.25°C	27.35°C	27.25°C	Point
6	2023-12-25 17:13:47	_thermal	26.75°C	27.45°C	28.15°C	Line 1
7	2023-12-25 17:13:47	_thermal	26.65°C	27.25°C	27.75°C	Area 7
8	2023-12-25 17:13:47	_thermal	25.95°C	27.05°C	27.85°C	Area 8
9	2023-12-25 17:13:17	_thermal	27.75°C	27.75°C	27.75°C	Point
10	2023-12-25 17:13:17	_thermal	27.25°C	27.95°C	28.55°C	Line 1
11	2023-12-25 17:13:17	_thermal	27.05°C	27.65°C	28.25°C	Area 7
12	2023-12-25 17:13:17	_thermal	26.35°C	27.45°C	28.35°C	Area 8
13	2023-12-25 17:12:57	_thermal	28.25°C	28.25°C	28.25°C	Point
14	2023-12-25 17:12:57	_thermal	27.75°C	28.45°C	29.05°C	Line 1
15	2023-12-25 17:12:57	_thermal	27.45°C	28.15°C	28.75°C	Area 7
16	2023-12-25 17:12:57	_thermal	26.75°C	27.85°C	28.85°C	Area 8
17	2023-12-25 17:09:37	_thermal	29.15°C	29.15°C	29.15°C	Point
18	2023-12-25 17:09:37	_thermal	28.75°C	29.25°C	29.75°C	Line 1
19	2023-12-25 17:09:37	_thermal	28.35°C	29.05°C	29.55°C	Area 7

Total: 217 50

1 /5Page

Start/End Time: The end time shouldn't be earlier than the start time.


Export: Click [Export] to export the temperature data to the Excel file as shown below.

	A	B	C	D	E	F	G
7	6	2022-01-13 14:41:59	Industrial tem	21.25°C	21.25°C	21.25°C	7
8	7	2022-01-13 14:41:59	Industrial tem	20.85°C	22.45°C	24.35°C	10
9	8	2022-01-13 14:41:48	Industrial tem	33.25°C	34.55°C	35.35°C	10
10	9	2022-01-13 14:40:28	Industrial tem	21.75°C	21.75°C	21.75°C	7
11	10	2022-01-13 14:39:07	Industrial tem	21.25°C	21.25°C	21.25°C	7
12	11	2022-01-13 14:38:57	Industrial tem	23.35°C	23.35°C	23.35°C	5
13	12	2022-01-13 14:38:16	Industrial tem	21.45°C	21.45°C	21.45°C	9
14	13	2022-01-13 14:37:36	Industrial tem	21.95°C	21.95°C	21.95°C	9
15	14	2022-01-13 14:37:26	Industrial tem	21.75°C	21.75°C	21.75°C	7
16	15	2022-01-13 14:36:05	Industrial tem	23.85°C	23.85°C	23.85°C	5
17	16	2022-01-13 14:34:14	Industrial tem	21.85°C	21.85°C	21.85°C	6
18	17	2022-01-13 14:33:24	Industrial tem	20.95°C	22.55°C	24.45°C	10
19	18	2022-01-13 14:33:14	Industrial tem	20.95°C	22.75°C	27.75°C	10
20	19	2022-01-13 14:32:34	Industrial tem	21.35°C	21.35°C	21.35°C	6
21	20	2022-01-13 14:32:04	Industrial tem	21.25°C	21.25°C	21.25°C	7
22	21	2022-01-13 14:32:04	Industrial tem	23.35°C	23.35°C	23.35°C	5
23	22	2022-01-13 14:28:31	Industrial tem	21.45°C	21.45°C	21.45°C	9
24	23	2022-01-13 14:28:11	Industrial tem	21.15°C	22.15°C	23.75°C	2
25	24	2022-01-13 14:27:30	Industrial tem	21.95°C	21.95°C	21.95°C	4
26	25	2022-01-13 14:27:09	Industrial tem	20.85°C	22.65°C	24.55°C	10

Delete: if the rule is deleted, all historical temperature measurement records under this rule will be deleted too.


19 User Management

Go to Home→User/Role as shown below.



There is a default super administrator by default. The username is admin; the default password is 1234. The super administrator cannot be deleted.


Modify the password of the super administrator:



If it is the first time for you to log in, please select the super admin user and then click [Edit Security Questions/Answers] to set the questions and answers. It is very important to reset the password if you forget your password.


Select the super administrator and then click [Edit Security Questions/Answers] to modify the questions and answers as needed after verifying the username and password.

Click "Role" to pop up the following interface.



Enter the role name and then check the permission as needed.

Put the cursor on the added role. Two icons will appear. Click  to add a user.




After the user is added under the role, put the cursor on the user name. Then a deletion icon will appear. Click it to delete the added user.

20 Operation and Maintenance Management

20.1 Check and Export Log

Go to Home→Operation and Maintenance Management.

Click the “Check and Export Log” tab as shown below. All types of logs can be searched and exported here.




No.	Main Type	Record Time	Node Name	Sub Type	User Name	User Address	Details
1	Operation Log	2023-10-18 20:28:37	Client	System Maintenance	admin		Log Search
2	Operation Log	2023-10-18 20:28:21	Device Name_Camera01	Preview video	admin	admin 10.15.1.155 CO...	Preview video: Device Name...
3	Operation Log	2023-10-18 20:24:49	Device Name_Camera01	Preview video	admin	admin 10.15.1.155 CO...	Preview video: Device Name...
4	Operation Log	2023-10-18 20:20:03	Device Name_Camera01	Preview video	admin	admin 10.15.1.155 CO...	Preview video: Device Name...
5	Operation Log	2023-10-18 20:19:55	Device Name_Camera01	Preview video	admin	admin 10.15.1.155 CO...	Preview video: Device Name...
6	Operation Log	2023-10-18 20:19:39	Device Name_Camera01	Preview video	admin	admin 10.15.1.155 CO...	Preview video: Device Name...
7	Operation Log	2023-10-18 20:19:25	Device Name_Camera01	Preview video	admin	admin 10.15.1.155 CO...	Preview video: Device Name...
8	Log Configuration	2023-10-18 20:19:21	Client	Channel Parameter	admin		

Select the log type, set the start time and the end time and then click [Search] to search logs. After the logs are searched, click [Export] to export these logs.

20.2 Backup and Restore Configuration

Go to Home→Operation and Maintenance Management. Click “Backup and Restore Configuration” to go to the following interface.



You can import the former system configuration files to the new version. Click [Backup System Configuration] in the last version to backup the system configuration files. Additionally, TV wall configuration also can be backed up as needed. Then click [Restore System Configuration] in the new version to restore the system configuration.

For TV Wall configuration restoration, you need to go to Home→TV Wall Management→TV Wall System Setting→TV Wall Backup interface and then restore TV Wall configuration by clicking [Restore TV Wall].

20.3 Viewing Online Status

Go to Home→Operation and Maintenance Management→Online Status interface.


You can view the online status of encoding device, decoders and storage servers and the record status of the storage server and encoding

devices.



20.4 Viewing Status Log

Go to Home → Operation and Maintenance Management → Status Log interface.



In this interface, record status, online or offline status of servers and monitor client can be viewed.

Set the start time and the end time and then click [Search] to search status logs.


The searched logs can be exported by clicking [Export].

21 Configuration

21.1 Local Configuration

21.1.1 Basic Settings

Go to Home→ Configuration→Local Configuration



Auto Login: if enabled the system will automatically log in when running this software next time.

Trigger audio when the node is offline: if enabled, the system will trigger audio when there is node offline.

Show tips when the node is offline: if enabled, the system will pop up tips when there is node offline.

Substream display of new view: if enabled, the new view will be displayed at substream.

Verify the password before exiting the program: if enabled, you shall enter the password before exiting the program.


Server exception Linkage: if enabled, the system will skip to real-time status interface when the server error occurs.

Sound Loop: If enabled, the alarm sound will be repeated continuously.

Temperature Unit: °C or °F can be selected

In this interface, you can also set video configuration rules, language, time display format and so on.

21.1.2 Resource Tree Settings




Full name display for DVR/NVR's channels: if enabled, the DVR/NVR's channel name listed in the resource tree will show the DVR/NVR

name and the channel name. If disabled, only the channel name is shown.

Resource tree automatically expands: please enable as needed.


Show alarm state for the monitoring point: if enabled, the alarm state will be displayed in the monitoring point list as shown below.



In addition, you can also select the resource tree sorting rules as needed.

21.1.3 Record and Snapshot Settings


Go to Home → Configuration.



In this interface, the playback source, backup file format and max file size for manual recording and record backup can be set up here.

21.1.4 Alarm View Settings


Go to Home → Configuration → Alarm View Setting.



In this interface, users can enable “Automatic Pop-up Alarm Page” or “Full Screen Display when Popping up”, set “automatically /manually close alarm page” and select the number of screens (1/4/6/19 optional).

21.1.5 Overload Settings

This system supports CPU and memory overload protection. When the system overloads, the monitor client will restrict the new live view and playback operation and the overload tip will prompt. Go to Home → Configuration → Overload Setting. Select the overload upper limit and then click [Apply] to save the settings.




21.1.6 Snapshot Attribute Display Settings

Go to Home→Configuration→Local Configuration→Snapshot Attribute Display Setting interface as shown below.

The snapshot attribute display and target box display can be set here.

Snapshot attribute display setting: you can set the attributes of face, human and vehicle. Please select the corresponding attributes/features as needed. The attributes of smart snapshot picture will be shown accordingly.



Face attributes/features:

Including gender, age, mask status, temperature, hat, hairstyle, beard, glasses, telephone, skin, a maximum of 6 features can be shown in the smart snapshot area.

Human attributes/features:

Including gender, age, hat, glasses, mask status, glasses, backpack, shoulder bag, upper clothing color, lower clothing color, upper clothing type, lower clothing type, dress/skirt, a maximum of 6 features can be shown in the smart snapshot area.

Vehicle attributes/features:

Including color, type, one or two attributes can be displayed in the smart snapshot area.

Target tracking box:

If enabled, the target tracking box will be shown on the preview/playback window which is playing the video of the IPC enabled the video metadata function.

21.1.7 Network Configuration

Click Home→Configuration→Local Configuration→Network Config to go to the following interface. Set the network parameter according to the actual condition.

IP Group Enable

IP Address

Subnet Mask

Gateway

Network Mode

Major DNS

Minor DNS

eth0 Bind static IP

MAC Address

IP Address

Subnet Mask

Gateway

21.1.8 Server Port Configuration

Click Home→Configuration→Server Port Config to go to the following interface.

<p>Authentication Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="6003"/></p>	<p>Config Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="7002"/></p>	<p>Media Transfer Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="6006"/></p> <p>Active report port <input type="text" value="2009"/></p>	<p>Alarm Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="6033"/></p>
<p>TV Wall Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="6036"/></p>	<p>Intelligent Analysis Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="6069"/></p>	<p>Http server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="8080"/></p>	<p>Application Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="6093"/></p>
<p>Access Server <input checked="" type="checkbox"/></p> <p>Port <input type="text" value="6013"/></p>			

In this interface, you can set the ports of authentication server, config server, media transfer server, alarm server, TV wall server, intelligent analysis server and so on. The service of all servers is enabled by default. Please set these ports as needed.

21.1.9 System Time Configuration

Click Home→Configuration→System time config to go to the following interface.

Zone

System time

Timing mode


Timing server

Please select the time zone as needed.

You can set the time manually or automatically as needed.

21.1.10 Upgrade System

Click Home→Configuration→Upgrade System to go to the following interface.



Please check “Delete database” or “Delete intelligence server data” as needed.

Insert the USB storage device into the device and then click [Select Upgrade File] to find the upgrade file. Then click [Upgrade System]. During the process of upgrading, please do not power off your device. After the upgrade is finished, the system will automatically reboot.

21.1.11 Other Configuration

Go to Home→Configuration→Other Config.




In this interface, you can enable system SSH service. This service is for test. In addition, you can also disable HTTPS here.

21.2 Server Configuration

21.2.1 System Settings

Click Home→ Configuration→Server Configuration→System Setting to go to the following interface.



System Name: Set the platform display name.

Choose “Device Time Correction” and “Synchronize Time Zone” and then click [Synchronize Platform Time] to synchronize the device times with the time of the platform.


Service fault determination time: set the failure duration time. When the server failure exceeds this period of time, it will be determined as “Offline”. The spare server will take over.

Log Retention Time: set the log storage time.

Enable License Plate Synchronization: if enabled, you can use the relevant license plate synchronization functions. See the tips shown in the interface for details.

21.2.2 Alarm Settings

Click Home → Configuration → Server Configuration → Alarm Setting to go to the following interface.



In this interface, you can enable “Alarm preview using third stream”.

Hide alarms beyond the alarm linkage schedule: Alarms will not be viewed beyond the alarm linkage schedule.

Enable and set the same alarm reporting interval and its linked alarm type. After that, the alarm type will automatically report according to the set interval.

Standard NVR alarm receiving options: please select to receive alarm information or snapshot and alarm information of NVR as needed.


21.2.3 Parking Lot Settings

Set the license language. Default or Arabic can be selected.

21.2.4 Audio Uploading Settings

Go to Home → Configuration → Server Configuration → Audio Uploading Setting.

Click [Add] to bring the following box.



Click  to choose the audio file and then enter the audio name. Click [OK] to save this audio. After the audio is uploaded successfully, you can listen to it.

22 Data Dashboard


Before opening the data dashboard, please make sure the intelligent server is online.

Go to Home→Resource Management→Intelligent Analysis Server interface. There is a default intelligent server and make sure it is online.


Add, Edit or Delete Device						
Device Setting						
Area Setting						
Channel Group Setting						
Task						
Encoding Device (Online/Total number: 2/3)	+	Server Name	IP Address	Port	Client Connection Status	Authentication Server Connection Status
		Intelligent Analysis Server	10.15.1.155	6069	Online	Online
Decoder (Online/Total number: 1/1)						
Intelligent Analysis Server (Online/Total number: ...)						

22.1 Create Intelligent Dashboard

Go to Home→Intelligent Dashboard.




Click [Immediately Create] to create the layout of the data dashboard. Drag the module you want to display to the right preview window as needed. After that, click [OK] to save the settings.




Hover the cursor onto the module in the preview window and then you will see a deletion button (). Click it to remove the module

from the preview window.




After the data dashboard is created, click  to display it in full screen mode. Click  or ESC to exit the full screen mode. Click  to set the layout of the dashboard.





22.2 Basic Module

Video window supports 4-screen display mode. Click  to extend the monitoring points. Drag the camera to the preview window or double click the camera to play the video. You can drag the playing window to other windows.





Other modules can set its attributes that you want to display as needed.



22.3 Face Comparison Display


Face Comparison display includes face comparison statistics and face comparison record display. In the layout interface, drag these two modules to the preview window. Then you can set the attributes as needed.



Smart Snapshot module: You can set the snapshot channel and attributes.


In the face comparison records, you can view the comparison similarity. Click  to quickly skip to face comparison retrieval interface.

Click  to pop up the detail box. In this box, you can modify the personnel information; click  to add this person to the face database.




22.4 Body Temperature Measurement Display

In the layout interface, select the body temperature module and then set the attributes you want to display as shown below.




The body temperature measurement of the intelligent dashboard is shown as below.




22.5 E-map Display

E-Map includes E-map monitoring and heat map analysis. The layout settings are as follows.




You need to set the hotspots in advance and then you can view here. Please refer to E-Map→E-Map Monitoring for details.




Heat map module: The more people/vehicles enter, the deeper the color is. Move the cursor on the monitoring point to view the current traffic flow. You need to set the E-map and hotspots in advance. Please refer to E-map settings chapter for details.

Besides the above hotspot setting, you can set other parameters as shown below.




In the heat map module of the intelligent dashboard, you can view the statistics of human/motor-vehicle/non-motor vehicle.





22.6 Smart Snapshot Display

You need to set the snapshot attributes in the layout interface and then the relevant data can be viewed on the dashboard. The smart snapshot type includes face, license plate, human body, motor vehicle and non-motor vehicle. Please select them as needed.



22.7 Traffic Flow Statistics Display

You need to set the statistical type, auto refreshing interval and channel in advance. Please refer to Target Counting → Task Management for details. Then set the layout of traffic statistics and display attributes.



22.8 Remaining Parking Space Display

Select the parking lot in the property area and then you can view the remaining parking lot here.



23 Troubleshooting

1. How to modify the password by yourself?

Login monitor client and then go to the User Management interface. Select the user to modify the password. Then click [Save].

The screenshot displays the 'User Management' interface with a 'Modify Password' dialog box open. The background interface includes an 'Enable' toggle, a 'User Name' field with 'admin', a 'Password' field with a 'Modify Password' button, a 'Role' field with 'Super Administrator', a 'Schedule' field with '7*24', a 'Bind MAC Address' field with '00 : 00 : 00 : 00', and a 'Remark' field. At the bottom of the background interface are buttons for 'Create Security Questions / Answers', 'Edit Security Questions', 'Save', and 'Cancel'. The 'Modify Password' dialog box has a blue header and a close button. It contains a 'User Name' field with 'admin', an '* Original password' field with 'Enter Password', a '* Password strength' section with radio buttons for 'Weak', 'Middle', and 'Strong' (selected), and a red note: '8-16 characters; numbers, special characters, upper case letters and lower case letters must be included.'. Below this are '* Password' and '* Confirm Password' fields, both with 'Enter Password' text. At the bottom of the dialog are 'OK' and 'Cancel' buttons.

2. The device information cannot be seen or the device is offline after the user logins.

- 1) Please check whether this user account is an administrator account. If this account is an operator account, please check whether it has the authority to view the device information.
- 2) Please check whether the media transfer server of the device has been started.

3. The alarm information cannot be received after the user logins.

- 1) Please check whether the schedule of sensor alarm, motion detection alarm and so on are set in the SPECO BLUE VMS system.
- 2) As for remote login device in the monitor client, please check whether alarms and alarm schedules of the remote login device have enabled.

4. The record cannot playback after the user logins.

- 1) Please check whether the storage server is online. If it is online, please check whether this account logged on has playback permission.
- 2) Please check whether the record source selected has record data. If you want to get record data from a storage server, please check whether to set the record schedule of the storage server or not.
- 3) Check whether there are record data in the playback channel and whether the record source and the start time and the end time of the playback is set up correctly.
- 4) Please check the record schedules of the storage server are set correctly.

5. The configuration of devices cannot be modified remotely after the user logins.

- 1) When the device configuration is required by the monitor client and prompts "Someone is configuring. Please try later", please open the IE browser to login to the device remotely and then go to "Online user" interface to see if there are any other users logging in.
- 2) Please go to the live to see whether the device is being set up.
- 3) If the problem still exists, please contact your device manufacturer.

Notes

1. Please use super administrator or standard user (permission control is set to "Never Notify") to log in operation system, install and use servers and client software.
2. The resolution of the surveillance client's monitor shall be more than 1280*960.
3. If you want to delete the files of a server, please stop the server first.

Model: SB01M

Federal Communications Commission (FCC) Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Responsible Party:

Speco Technologies
200 New Highway
Amityville, NY 11701
www.specotech.com