

Quick Start Guide

O4BXLP1M



Welcome

Thank you for purchasing this network camera!

This owner's manual is designed to be a reference tool for your system.

Please read this manual carefully before operating the unit and retain it for future reference. $Should \ you \ require \ any \ technical \ assistance, \ contact \ Speco \ Technologies \ Tech \ Support \ at \ 1-800-645-5516$

Important Safeguards and Warning

1. Electrical safety

All installation and operation here should conform to local electrical safety codes.

Use a certified/listed 24V DC/AC power supply or adequate PoE switch.

Please note: The product must be grounded to reduce the risk of electric shock. Improper handling and/or installation could run the risk of fire or electrical shock.

2. Environment

Do not expose the unit to heavy stress, violent vibration or long-term exposure to water and humidity during transportation, storage, and/or installation.

Do not install near sources of heat.

Only install the product in environments inside the specification operating temperature and humidity range

Do not install the camera near power lines, radar equipment or other electromagnetic radiation. Do not block any ventilation openings if any.

Use all the weatherproofing hardware requirement to minimize weather intrusion.

3. Operation and Daily Maintenance

 $Please \ shut \ down \ the \ device \ and \ then \ unplug \ the \ power \ cable \ before \ you \ begin \ any$ maintenance work.

Do not touch the CMOS sensor optic component. You can use a blower to clean the dust on the lens surface. Always use the dry soft cloth to clean the device. If there is too much dust, use a cloth dampened with a small quantity of neutral detergent. Finally use the dry cloth to clean the device.

The grounding holes of the product are recommended to be grounded to further enhance the reliability of the camera

The lens is an optical device, please don't touch or wipe cover surface directly during installation and use, please refer to the following methods if dirt is found:

Stained with dirt: Use oil-free soft brush or hair dryer to remove it gently.

Stained with grease or fingerprint: Use oil-free cotton cloth or paper soaked with alcohol or detergent to wipe from the lens center outward. Change the cloth and wipe several times if it is not clean enough.

Warning

This camera should be installed by qualified personnel only. All the examination and repair work should be done by qualified personnel. Any unauthorized changes or modifications could void the warranty.

Statement


This guide is for reference only. Product, manuals and specifications may be modified without prior notice. Speco Technologies reserves the right to modify these without notice and without incurring any obligation. Speco Technologies is not liable for any loss caused by improper operation.

Note:

Before installation, check the package and make sure that all components are included. Contact your rep or Speco customer service department immediately if something is broken or missing in the package


Package








Unscrew the sunshield and then remove the upper cover of the housing as shown above.





Cable Connection 3



Installation 4

Wall Mounting (* WMT3 is not included)







Washe

4. Screw four expansion bolts into the hole and then remove their nuts and washers.

5. Pull the cable through the cable entry of the bracket and then connect the cables. Then fix the bracket onto the wall with the nuts and washers




3. Paste the drill template onto the wall and then drill the screw holes according to this drill template.




6. Adjust the depression angle and pan angle by loosening the two screws indicated above. After that, tighten these two screws

Pole Mounting (* PMT3 is not included)



Installation Height Requirement



Lens: 8-32mm

Installation Height(H): 15~20ft


Recommended Plate Capture Distance(D): 23-115ft

Please ensure the depression angle of the camera

installed is within 25°.

The camera is available for a 8~13ft wide lane.

Caution: Be mindful when positioning the camera as its built-in illumination may cause temporary glare to approaching drivers.




5 Web Operation and Login

IP Scanner can search for the device on the local network.

• Operation

① Make sure that the camera and the PC are connected to the same local network. The camera is set to DHCP by default. 2 Install IP Scanner from the CD and run it after installation. Or download IP Scanner or Speco Blue Scanner from https://www.specotech.com



③ In the device list, you can view the IP address, model number, and MAC address of each device. Select the applicable device and double click to open up the web viewer. You can also manually enter the IP address in the address bar of the web browser.



The login interface is shown above. Default user name is admin and password is 1234. After logging in, follow directions to install applicable plugins if prompted.