

Quick Setup Guide (Ver.2.6)

Speco Technologies SecureGuard® Server
Model: SG719(2U)



About this Quick Setup Guide

Before operating the unit, please read this user's guide thoroughly and retain it for future reference.

Product Components


The following components are included:

SecureGuard® Server	 QTY: 1 **Server comes with rack ears mounted**
Quick Setup Guide	 QTY: 1
Power Cable	 QTY: 2
Server Rails (Instruction Manual Included)	 QTY: 1 pair
Rack Bracket Adapters	
Hardware	

Internal Connections



Front View



Rear View

Internal Connections continued

- Power Switch
- Reset Switch and LED Status Indicators

	Power Failure LED: Flashing LED indicates power supply failure.		NIC2 Activity LED: Indicates network activity on LAN 2 when flashing.						
	Information LED:		NIC1 Activity LED: Indicates network activity on LAN 1 when flashing.						
	<table border="1"> <thead> <tr> <th>STATUS</th> </tr> </thead> <tbody> <tr> <td>Continuously on and red</td> </tr> <tr> <td>Blinking red (1 Hz)</td> </tr> <tr> <td>Blinking red (0.25 Hz)</td> </tr> <tr> <td>Solid blue</td> </tr> <tr> <td>Blinking blue (300 msec)</td> </tr> </tbody> </table>	STATUS	Continuously on and red	Blinking red (1 Hz)	Blinking red (0.25 Hz)	Solid blue	Blinking blue (300 msec)		HDD Activity: Indicates drive—S AS/ SATA, SCSI, and or DVD-ROM—activity when flashing.
STATUS									
Continuously on and red									
Blinking red (1 Hz)									
Blinking red (0.25 Hz)									
Solid blue									
Blinking blue (300 msec)									
			Power Status: Indicates power is being supplied to the power supply units.						

- 3.5" HDD Bays x12
- AC Inputs for Redundant Power Supply
- 2.5" HD Bay x2
- DB9 COM Port
- IPMI Interface x1
- USB 2.0 x2, USB 3.0 x2
- 10 Gigabit Ethernet LAN ports x2
- VGA Output
- 2 Mini-SAS HD SFF8644 x2

Power on the Server

- Please follow the proper power ON procedures to avoid damaging the server.
- Connect all necessary components, e.g. monitor and cameras, before powering the server.
- Power ON the server by depressing the Power Switch (1) to boot up the server.

WARNING: To reduce the risk of database corruption due to power loss, Speco strongly urges use of an uninterruptible power supply with our SecureGuard® servers.

Login to Windows

- After boot up, at the Windows login screen, you will see that the default user account is "Speco Tech". There is **no password** associated with the default account. It is **highly advisable** to set a password after logging into the Windows home screen for the first time. See *Image 1*.



Image 1

WARNING: Please store your password in a safe location. Speco Technologies will not be able to assist you in recovering a lost password.

Run SecureGuard® Configuration Tool

Note: The server comes pre-loaded with SecureGuard® Server software.

- At the Windows Desktop home screen, run the SecureGuard® Configuration Tool to setup the server by double clicking on the SecureGuard® Configuration Tool icon. See *Image 2*.



Image 2

- If prompted to select or create a System Recordings folder, point to the storage drive where the recordings will be stored (Recordings D:). Otherwise move on to the next step. See *Image 3*.

Note: SecureGuard® servers come with independent hard drive(s) for the storage recordings and the operating system. **DO NOT** store recordings on the hard drive dedicated for the operating system.




Image 3

Run SecureGuard® Configuration Tool continued

- When prompted, enter the default username **admin** and default password **admin** to access the SecureGuard® Configuration Tool. See *Image 4*.




Image 4

- At the "System" tab, ensure "System Recordings" file path is pointing to the storage drives. See *Image 5*.




Image 5

- Reminder:** SecureGuard® servers come with independent hard drive(s) for the storage recordings and the operating system.

DO NOT store recordings in the hard drive dedicated for the operating system.

Setting up Software Updates

- SecureGuard® will be set to check for updates on a daily basis. The time to check for updates can be modified by simply changing the hour, minute, and meridiem. You can manually check for updates by clicking "Check Now". See *Image 6*.




Image 6

- Note:** Server must be connected to the internet to search and download updates.

- To disable the scheduled update check, uncheck the box next to "Enable Automatic Updates". Click "Apply" to confirm changes.

Setting up Database Backup

- The "Database" tab is where you import or export settings and back up, restore, or validate the SecureGuard® database. See *Image 7*.




Image 7

- Choose where you would like to backup your database by clicking "Browse".
- Note:** It is **HIGHLY** recommended that you backup your database to a separate drive and NOT to your C: drive.

Adjust the time's hour, minute, and meridiem to specify what time the database will be backed up. And lastly, select whether the database will be backed up on a daily basis or weekly basis. Once completed, click "Apply". See *Image 8*.




Image 8

Setting up Network

- Note:** For servers with Dual Network Interface Cards, it is **highly advisable** that the camera and the client connection network traffic be kept separate.



Image 9

- In the "Network" tab, for "Client Interface" select the network adapter that remote client(s) will connect to. For "Video Interface" select the network adapter that the camera(s) will connect to. See *Image 9*.

- To register the server with Speco's Free DDNS, ensure the "Enable Speco DDNS" checkbox is selected, and enter a name for the server in the "Host Name" field and click on "Submit/Update". See *Image 10*.



Image 10

- If the server name isn't currently registered with Speco's DDNS server, then the registration will be successful. If it fails, use a different name for the "Host Name". See *Image 11*.




Image 11

- By default, the server uses ports 7312 and 7313 for network communication.

- Note:** To avoid network conflicts with devices that also use the server default ports **7312**, **7313**, and **7314** the option of changing the port numbers is available through the Configuration Tool. The servers come shipped with an inbound rule for Window's firewall that allows communication on the server default ports. If the server default ports are changed, please ensure the existing inbound rule is updated, or create a new inbound rule permitting communication on the new server port values.

Adding Sites (IP Cameras, DVRs, NVRs, Mobile Devices)

- The "Sites" tab is where sites (IP cameras, DVRs, NVRs, and mobile devices) can be added, deleted or updated. There are two methods of adding sites to the server. The first method uses "Site Locate" which automatically scans the Local Area Network for IP cameras and select DVRs, NVRs, and hybrid DVRs. See *Image 12*.




Image 12

- Clicking on "Site Locate" will open the "Site Locate" window and start scanning the local area network for your devices. You can rescan the network by clicking on "Refresh". See *Image 13*.




Image 13

- Clicking on "Site Settings" will open the "Site Settings" window. Ensure the values for all the fields are accurate, enter the camera's login credentials, and verify the accuracy of the information by clicking on "Check Site". If the connection is successful, click "OK". See *Image 14*.




Image 14

To add a site to the server, double click on the device to bring up the "Site Settings" window. Ensure the values for all the fields are accurate, enter the camera's login credentials, and verify the accuracy of the information by clicking on "Check Site". If the connection is successful, click "OK". See *Image 14*.

Quick Setup Guide (Ver.2.6)

Speco Technologies SecureGuard® Server Model: SG719(2U)

Adding Sites (IP cameras, DVRs, NVRs) continued

- The devices will now be listed under “Sites to add” list.
- Continue to repeat this process for the remaining IP cameras that must be added to the server. Once complete, click on “OK” to exit the “Site Locate” window. The cameras that were added to the “Sites to add” list will now be made available in the “Sites” tab. Click on “Apply” to complete adding the sites to the server. *See Image 19.*
- The second method of adding sites to the server is by manually entering the site information. This method must be used when adding mobile devices as well as DVRs, NVRs, and hybrid DVRs not scanned in ‘Site Locate’. To enter site information manually, click on “New” in the “Sites” tab to bring up the “Site Settings” window. *See Image 15.*
- Fill in the values for all the fields, and verify the accuracy of the information by clicking on “Check Site”.



Image 15




Image 16

- **Note:** A “Check Site” should always be performed when adding a DVR/NVR/Hybrid. Doing so will confirm the number of channels on the site in order to toggle PTZ control for the channels and, if needed, restrict users from specific channels in the client.




Image 17

- Correct any information by clicking ‘Fix’. *See Image 16.*




Image 18

- Click “OK”. *See Image 17.*
- The channel boxes under PTZ Control will now be consistent with the number of channels on the DVR, NVR, or Hybrid. Perform another “Check Site”. If the connection is the successful, click “OK” on both windows. *See Image 18.*




Image 19

Setting Up Schedule Recording

- To set up a recording schedule, click on the “Schedules” Tab.
- Next to “Action:” select the type of recording—Continuous, Motion, or Sensor—by clicking on the button (radio button) next to it.
- The schedule grid is made up of rows and columns. The rows pertain to the days of the week (Mon-Sun), and the columns pertain to the hours of a day (00HR-23HR).



Image 20

Setting Up Schedule Recording continued

- The cells inside the schedule grid can be colored in based on the type of recording selected. The color representation is as follows: Green for Continuous, Blue for Motion, Orange for Sensor, and White for No Recording. To color in the grid, hold down the left mouse button and drag the mouse cursor over the grid. *See Image 20.*




Image 21

- To set the entire schedule to a single recording type, click on the white box located in the top-left most corner of the grid. *See Image 21.*

- Once the schedule and recording type has been set, associate the schedule with individual sites (IP cameras, DVRs, NVRs) by moving over the sites listed under “Available Site...” to “Sites using schedule...” by clicking on >>>

- Click on “Apply” to save the schedule.

Adding Users

- **Note:** By default, the server comes loaded with 3 user accounts—Admin, User, and Guest.




Image 22

- Go to the “Users” tab, here you can add, edit, or delete users, and manage user site privileges through roles and permissions.

- To add users, click on “Add User” *See Image 22.*

- The “Add User” window will pop up. *See Image 23.*




Image 23

- **Note:** While the User Password is filled in, it actually has no password assigned to it.
- Enter the new user credentials, and select a “User Role” based on the level of access you wish the user to have. An “Administrator” role has full access to the system and sites. The permissions associated with this role cannot be modified. The “User” and “Guest” roles have limited access, but the permissions can be modified. Users and Guests can also be restricted to specific sites and channels by toggling the boxes next to the sites and channels. *See Image 24.*




Image 24

- **Note:** A customized role can be created to meet varying levels of access control.
- The name and email field are not mandatory.
- Click on “OK” to exit the “Add User” window, and click on “Apply” in the “Users” tab to add the user(s) to the system.

Installing SecureGuard® Client on Client PCs

- Download the latest version of the SecureGuard® Client from our website. (www.specotech.com)
- Once the client software has been downloaded, start the installation by running the executable file.
- Uncheck the components you don't wish to install on the client computer. This option is limited to the following components:
 - SecureGuard® Streaming Audio App
 - SecureGuard® Player
 - Start Menu Shortcuts
 - Desktop Icon

Installing SecureGuard® on Client PCs continued

- Components deemed necessary for the operation of SecureGuard® Client cannot be unchecked. Click on “Next” to proceed. *See Image 25.*




Image 25

- Select the destination folder where SecureGuard® Client will be installed by clicking on “Browse”, or use the suggested destination folder which SecureGuard® Client will create. Click on “Install” to proceed. *See Image 26.*



Image 26

Startup & Live View

- Once the installation is complete, the SecureGuard® Client user login window will open. If not, run the application by double clicking on the SecureGuard® Client desktop icon.

- At the user login window, enter the server address. The server address can be the IP address of the server or the DDNS name. If using the latter, please make sure “Use DDNS” checkbox is checked and then click on “OK”. *See Image 27.*




Image 27

- Once logged in, the SecureGuard® Client Welcome window will pop up. Click “OK” to proceed. *See Image 28.*



Image 28

- Next, the User Settings window will pop up. Here the sites that were added to the server will be listed under Saved Sites. *See Image 29.*




Image 29

Startup & Live View continued

- In order to view the sites, they need to be placed in a group. To start off, a default group has already been created named Group. To add the sites to Group, click on >>>




Image 30

- After adding the sites, click on “Apply”. The “Apply” button will be grayed out, indicating the sites have been added to Group. Click on “Close” to exit the User Settings window. *See Image 30.*

- The Open Group window will pop up listing all the groups and sites. Select **Group** and click on “OK” to begin viewing the sites added to **Group**. *See Image 31 and Image 32.*




Image 31



Image 32